

75/76-123/125/126 Metal Bed
Assembly Instructions

Hardware List

CODE	DESCRIPTION	NUM
A	 Bolt 5/16"×5/8"	8
B	 Bolt 5/16"×1-3/8"	12
C	 Nut	8
D	 Allen Key	1
E	 Wrench	1

Attention: Please don't over tighten the bolts when assembly.

Step 1: Attach the bed rail to the headboard and footboard with bolt(B) Tighten the bolts(B) with allen key(D).

Step 2: Attach the 4 support legs to the bed slats by turning the bolts on the legs into the inserts in the middle of the slat.

Step 3: Put the bed slats onto the bed rail cleats, adjust the levelers at the bottom of the support legs to give proper support. Assemble the slats with the bed rail with bolts(A) and nuts(C). Tighten the nuts(C) with wrench(E).

