

# INSTALLATION INSTRUCTIONS



## step1

First, locate two fully assembled cabinets, and then find two wooden spacers.



## step2

Align the wooden gasket with the hole position on the top of the cabinet, and then use the corner pieces provided in the packaging to fix it.



## step3

Then place the desktop on top of the wooden spacer, make it flat and align it properly, and then fix it using angle iron.



## step4

Next, install the baffle. As before, place the baffle in position and then simply fix it with angle iron. Installation is complete.

