

3. Install the two (2) leg supports and footrest by using screws 'A', 'B', 'C' and 'D' nuts. (Fig-4)

- a. Begin by joining the two (2) leg supports using screw 'C' and a nut through the center hole. The holes on the leg supports should extend downwards.
- b. Next, install the footrest onto the front side of chair. Screws 'A' (the two longer screws) needs to pass through the foot rest, then the chair leg and the leg support before securing with a nut.

*The leg support with the "O" marking should be on the left-hand side. (Fig-5)*

Adjust the chair leg by twisting it to align hole for screw.

Finally, attach the leg supports to the back legs using screws 'B' (the two shorter screws) and remaining nuts.



(Fig-4)



(Fig-5)

4. Put the tray on the handrail. (Fig-6)

5. Press the tray to make sure it is securely locked in place. (Fig-7)

6. Make sure the seat cover is put in right place in seat. (Fig-6)

Check high chair again to make sure everything is OK before use.



(Fig-6)



(Fig-7)