


OUTDOOR WALL LANTERN USE AND CARE GUIDE



INSTALLATION INSTRUCTIONS FOR OUTDOOR WALL LIGHT




INSTRUCTIONS PERTAINING TO RISK OF FIRE OR INJURY TO PERSONS
READ ALL INSTRUCTIONS


**IMPORTANT SAFETY
INSTRUCTIONS**
SAVE THESE INSTRUCTIONS

Before starting the installation, disconnect the Power by Turning Off the Circuit Breaker. Turning the Power Off using the LightSwitch is not sufficient to prevent electrical shock. All electrical connections and installation must be following local codes, ordinances, and/or National Electric Code and Must Be Done by an Electrician Only.

TYPE			
QTY	3pcs	2pcs	2pcs





WIRE NUT USAGE STEPS



Installation Notice:

Please install the light fixture in the correct orientation as shown in the diagram. Damage caused by incorrect installation, resulting in water ingress, is not covered by the warranty.



ASSEMBLY INSTRUCTIONS

TOOLS AND MATERIALS REQUIRED:



Phillips
Screwdriver




Wire Cutters




Safety Gloves



Ladder



Electrical tape



Mastic Silicone
Rubber




Safety Glasses

SAFETY PRECAUTIONS:


1. Turn off electrical power before starting the installation of the light fixture.
2. This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.
3. Firmly attach the fixture ground wire (bare copper) to the mounting bracket with the ground screw (by wrapping around the ground screw) and then connect it to the house supply ground wire with a wire nut.
4. To clean the fixture, turn off the power, wait for it to cool, and wipe the fixture with a clean, soft cloth.

INSTALLATION:


Note: the product may not look exactly as shown in the figures.




1. Secure the round mounting bracket to the outlet box. Make sure the studs on the mounting bracket are facing out from the junction box.




2. Firmly attach the fixture ground wire (bare copper) to the round mounting bracket with the ground screw (by wrapping around the ground screw) and then connect it to the house supply ground wire with a wire nut. Connect the black wire from the fixture to the black wire in the junction box with a wire nut. Connect the white wire from the fixture to the white wire in the junction box with a wire nut.




3. Once connections of wires are completed, carefully tuck wires and wire nuts into the junction box making sure no bare wire (on the black and white) is visible at the wire nuts.



4. Secure the two studs on the round mounting bracket to the outlet box with cap nuts.




5. Insert the glass column from the bottom upwards and secure it with screws and a backing plate to ensure it is stable and firmly in place.



6. After Installation, seal around the top and side perimeter between the fixture and the wall surface with weather-resistant caulking. The bottom should be left un-caulked to prevent moisture build-up. Apply a small amount of weather-resistant caulking around the side perimeter between the cap nut and the mounting plate.

DUSK TO DAWN SENSOR



Product Features

Built-in Dusk to Dawn Sensor:

Built-in IC sensor in our wall light will sensitively detect the brightness of surroundings, automatically on at night when the brightness of surroundings is less than 10 LUX; it will auto-off when it's at daytime, saving more energy and electric bills for your life

Upgraded LED with Energy Saving

This outdoor porch light is equipped with a 10W integrated LED, which could emit 3000K warm white light with 520 lumens and provide over 28,000 hours of life span. Long-lasting LEDs are high efficiency and maintenance-free. No bulb is required. Largely reduce your electricity bills, and save your money.

Weather Resistance:

This LED wall light is rust-resistant, durable metal, and has solid bubble crystals. Waterproof, suitable for wet locations.

1-YEAR LIMITED WARRANTY*

This light fixture is warranted against defects in material and quality for a 1-year period from the purchase date.

Exclusions from Warranty:

- Damage caused by acts of nature, such as lightning damage or corrosion and discoloration of components.
- Damages resulting from abuse, improper installation, electric surges, or actions of third parties.
- Costs related to removing and resealing the lighting fixture.
- Damage caused by incorrect installation orientation.

If this product fails for any reason covered by this warranty, feel free to contact us.