


User Manual

Floor Lamp



锥形一字布罩落地灯-美规

尺寸:A5 (展开尺寸: 296*210mm 对折尺寸: 148*210mm)

材质:128g铜版纸+正反面1C+对折

封面封底背面留白

Thank you for purchasing our product. Please read the following instructions carefully before assembly. If you have any question, please contact us.

Cautions

- 1. When opening the package with a sharp tool like a utility knife, be careful not to damage the components inside.
- 2. Carefully remove all packaging materials and keep them for future use.
- 3. Keep all hardware parts and packaging out of the reach of small children.
- 4. Please check whether the packing list is complete. If there are missing or damaged accessories, please contact us.
- 5. Do not allow children to play with this product.
- 6. Please make sure that the voltage is 100-120V, which is standard for US. This product can only be used between 100-120V.

Warranty


Make it cozy, make it home. Which is the goal that we have been pursuing. We'd like to provide the best product and service to you. We provide a 12-month warranty for you (Excludes incorrect installation or other man-made damage).

If you have any questions or suggestions, please feel free to contact us

Specifications


Lamp	
Power For blub	Max 60W
Material	Iron+Fabric
Socket Type	E26
Power	100-120v

Package List



Assembling

- ①-④ Assemble the lamps pole. Starting from the bottom and working up, connect the 4 segments of the lamp pole to each other.
- ⑤ Connect the assembled lamp pole to the base.
- ⑥-⑧ Assemble the lampshade and lampshade bracket.
- ⑨ Install the assembled lampshade onto the E26 lamp holder.
- ⑩ Install the lamp holder nut onto the E26 lamp holder and secure the lampshade bracket.




Usage

On/Off: ① Step on the foot switch.

② Press switch button on the remote control.

CCT: Press the color temperature +/- button, short press is for grading dimming, long press is for stepless dimming.

Brightness: Press the brightness +/- button, short press is for grading dimming, long press is for stepless dimming.



Matching

Make sure the remote control matches well with the lamp :

Plug the adapter to the power supply and use the remote to control the lamp. Usually the remote controls the lamp perfectly.

If the remote control doesn't work for the lamp, please re-match them.

Matching process :

1. Disconnect the power supply for more than 10 seconds.
2. Connect the power supply.
3. Press and hold the On/Off button (power icon) on the remote within 5 seconds.
4. When the light flashes, it matches successfully.

