

## SPECIFICATIONS

Model	EUH1500 (All specifications +5% / -10% tolerance)
BTU's per/Hour	5120
Voltage	120V
Watts	1500
Amps	15
Plug Type	Nema 1-15P
Heating Area	250

## TROUBLE SHOOTING

PROBLEM	CAUSE	SOLUTION
Heating element does not glow red	Stainless steel elements won't glow red to produce heat.	Heater is operating correctly
Do not feel heat or air flow	No power to heater	Check power connection to heater
	Desired room temperature reached.	Thermostat will shut off heater once desired room temperature is reached.
	Auto-Reset has tripped	Unplug heater allow to cool down for 10 minutes, then restart.
	Heater has fan only setting.	Set to run on full power for heating.