

ASSEMBLY INSTRUCTIONS

ITEM CODE : IN 4047

ITEM DESCRIPTION : BENCH

1

Reverse the Bench top & place the leg as shown & align the leg to match the apron.



Place the bolt in the cut out & tighten it with allen key provided,

2



3



Fix the other legs in the similar way



4

Reverse the Bench straight. Now your Bench is ready for use



