User Manual

Welcome

Thanks for purchasing this **Lighted Christmas Reindeer & Sleigh,** Please read this user manual carefully before use.

Package List

*1× Reindeer
*1×Sleigh
*2×Bows
*4× Triangle Stake Plates
1× Screwdriver
*1 Bag×Screws & Nuts
*1× User Manual

Specification

*Material: 304 Stainless Steel Support Plates+Iron Frame
*Power Supply: 3Pcs AA Batteries(Not Included)
*8 Lighting Modes: Combination, In Wave, Sequential, Slo Glo, Chasing/Flash, Slow Fade, Twinkle/Flash, Steady On
*Light Color: Warm Yellow
*LED Quantity: 50 Beads
*LED Strap Length: 517cm/203.54in/16.97ft
*Distance Between 2 Beads: 10cm/3.94in

Highlights

*With bow design and red & gold hue, the gentle buck and adorable sleigh create a unique festive atmosphere, captivating every guest that arrives.
*Designed with 8 light modes for appealing lighted display.
*Made of sturdy iron frame, moisture-proof, rustproof, wear-resistant. A reusable and appealing decoration for every Christmas!
*Easy to install. All needed tools is in the package.
*A perfect Christmas decoration for both indoor and outdoor use, suitable for party, office, living room, bedroom, garden, patio, yard, lawn and so on.

User Manual

Welcome

Thanks for purchasing this **Lighted Christmas Reindeer & Sleigh,** Please read this user manual carefully before use.

Package List

*1× Reindeer
*1×Sleigh
*2×Bows
*4× Triangle Stake Plates
1× Screwdriver
*1 Bag×Screws & Nuts
*1× User Manual

Specification


*Material: 304 Stainless Steel Support Plates+Iron Frame
*Power Supply: 3Pcs AA Batteries(Not Included)
*8 Lighting Modes: Combination, In Wave, Sequential, Slo Glo, Chasing/Flash, Slow Fade, Twinkle/Flash, Steady On
*Light Color: Warm Yellow
*LED Quantity: 50 Beads
*LED Strap Length: 517cm/203.54in/16.97ft
*Distance Between 2 Beads: 10cm/3.94in


Highlights

*With bow design and red & gold hue, the gentle buck and adorable sleigh create a unique festive atmosphere, captivating every guest that arrives.
*Designed with 8 light modes for appealing lighted display.
*Made of sturdy iron frame, moisture-proof, rustproof, wear-resistant. A reusable and appealing decoration for every Christmas!
*Easy to install. All needed tools is in the package.
*A perfect Christmas decoration for both indoor and outdoor use, suitable for party, office, living room, bedroom, garden, patio, yard, lawn and so on.

How To Install

* Assemble the frames with screws and nuts as picture.
* Fix the Buck's legs with 2 silver support wires.
*For triangle stake plates, you can install one or two on the legs of buck. He will be more stable when you place outdoors.





LED Strap Installation &Use

*Insert 3 AA batteries into the battery box.
*Wind the LED strap on the buck and sleigh freely.
*Short press the Power button of the battery box to turn on the light.
*Short press the Power button to switch light modes.
*Short press the Power button for 9 times to turn off the light.

Note:

Mare sure that batteries are to be inserted with the correct polarity.

FAQ

Question 1: Can the deer be placed outdoors for decoration?

Answer: Yes, but please note that it may take other measures to secure the deer in windy condition. The string light is not waterproof, please don't use the light in rainy days.

Question 2: Can the reindeer stand without supporting?


Answer: The reindeer is 2D design. We provide triangle stake plates for further stability.


Question 3: If one of the LED beads is unlit, can other beads be lit?

Answer: Yes. The other beads will still work.

How To Install

* Assemble the frames with screws and nuts as picture.
* Fix the Buck's legs with 2 silver support wires.
*For triangle stake plates, you can install one or two on the legs of buck. He will be more stable when you place outdoors.





LED Strap Installation &Use

*Insert 3 AA batteries into the battery box.
*Wind the LED strap on the buck and sleigh freely.
*Short press the Power button of the battery box to turn on the light.
*Short press the Power button to switch light modes.
*Short press the Power button for 9 times to turn off the light.

Note:

Mare sure that batteries are to be inserted with the correct polarity.

FAQ

Question 1: Can the deer be placed outdoors for decoration?

Answer: Yes, but please note that it may take other measures to secure the deer in windy condition. The string light is not waterproof, please don't use the light in rainy days.

Question 2: Can the reindeer stand without supporting?

Answer: The reindeer is 2D design. We provide triangle stake plates for further stability.

Question 3: If one of the LED beads is unlit, can other beads be lit?

Answer: Yes. The other beads will still work.