






Installation & Assembly



YOU MAY NEED (NOT SUPPLY)




ASSEMBLY DIAGRAM



PARTS LIST					
PARTS LIST					
NO	DESCRIPTION	QTY	NO	DESCRIPTION	QTY
①	Left side panel 	1	⑦	Top Decorative Panel 	1
②	Right side panel 	1	⑧	Right door panel 	1
③	Bottom panel 	1	⑨	Bottom Decorative Panel 	1
④	Front fixed panel 	1			1
⑤	Back fixed panel 	1			1
⑥	Back fixed panel 	1			


PARTS LIST					
HARDWARE LIST					
NO	DESCRIPTION	QTY	NO	DESCRIPTION	QTY
A	Three-in-one eccentric wheel 	16	G	4*23mm screw 	1
B	Three-in-one connecting rod 	16	H	Door handle 	1
C	Three-in-one sticker 	16	I	Small adjustable foot 	4
D	8*40mm wood dowel pins 	10			
E	4*16mm screw 	12			
F	Door hinges 	2			
CAUTION: Please confirm the parts list before installation					

STEP 1


HARDWARE LIST			
Three-in-one connecting rod B  16PCS	8*40mm wood dowel pins D  2PCS	Small adjustable foot I  4PCS	

1.Put the three-in-one connecting rod in the 10mm hole of the following panels and tighten them with a cross screwdriver or an electric tool.


2.Fix the small adjustable feet on the bottom of the left and right side panels



STEP 2





1.Strike the 08*40mm wood dowel pin into the 8mm hole of the above panels with an iron hammer. Please note that the hole of the three-in-one connecting rod should also be 8mm. The hole of the three-in-one connecting rod connects to the hole of 15mm three-in-one eccentric wheel.




HARDWARE LIST	
8*40mm wood dowel pins D  8PCS	

STEP 3




1. Connect No. 3 panel to No. 9 panel tightly with the three-in-one eccentric wheel.





2. Cover the mounting hole of the eccentric wheel with a three-in-one sticker.


HARDWARE LIST

Three-in-one eccentric wheel A  2PCS	Three-in-one sticker C  2PCS	
---	---	--

STEP 4




1. Connect No. 3-4-5-6-7 panel to No. 2 panel tightly with the three-in-one eccentric wheel.





2. Cover the mounting hole of the eccentric wheel with a three-in-one sticker.


HARDWARE LIST

Three-in-one eccentric wheel A  7PCS	Three-in-one sticker C  7PCS	
--	--	---

STEP 5



1. Connect No. 1 panel to No. 3-4-5-6-7 panel tightly with the three-in-one eccentric wheel.




2. Cover the mounting hole of the eccentric wheel with a three-in-one sticker.


HARDWARE LIST

Three-in-one
eccentric wheel
A  7PCS


Three-in-one
sticker
C  7PCS




STEP 6




○ H




1. Install the hinge cup to the door panel with 4*16mm screws.




2. Install the hinge to the side panel with 4*16mm screws.



4. Adjust the door panel clearance.



①



②


3. Install the hinge cup on the door panel to the hinge of the side panel.

HARDWARE LIST				
4*16mm screw	Door hinge	4*23mm screw	Door handle	
E 12PCS	F 2PCS	G 1PCS	H 1PCS	


Hinge/Door Adjustment and Realignment

If adjustment or realignment is needed, follow the instructions provided in the following chart.


Vertical adjustment




1. Loosen screws







2. Adjust hinge







3. Tighten screws



Horizontal adjustment



Door gap adjustment





Choking hazard-Small Parts : This unit contains small parts, not for children under 3 years.

Tip-over hazard : Secure finished unit to wall stud using L-Bracket and wall screw (#10*1.5"W/out provided). If a wall stud is not neccessible , Consault your local hardware store for appropriate mounting hardware . Failure to properly install will result in product collapse or tip-over. Serious injury can occur .