



FOR REPLACEMENT PARTS OR HELP WITH ASSEMBLY PLEASE CONTACT US

PLEASE ENSURE TO HAVE THE MODEL #
FROM THE PACKAGING OR INSTRUCTION BOOKLET

TO RETURN THE PRODUCT:

PLEASE CONTACT THE RETAILER

WHERE THE ITEM WAS PURCHASED FROM

IMPORTANT: Please read this manual carefully before beginning assembly of this product. Keep this manual for future reference.

SAFETY INFORMATION

Identify all the parts and hardware. Do not discard of the packaging until you have checked that you have all of the parts and hardware required. Hardware package may have spare parts.

WARNING: This item contains small parts which can be swallowed by children and pets. Keep children and pets away during assembly. To avoid danger of suffocation, always keep plastic bags away from children and pets. We recommend that you assemble this unit on a carpeted floor to avoid scratches. If using power tools, set the tool to low torque to avoid damage.


May require 2 people for ease of assembly.


CARE and MAINTENANCE


To clean, use a soft or slightly damp cloth, then wipe with a clean, dry cloth. Dust with soft dry cloth.

Do not use ammonia-based cleaning products, as they will damage the finish. Do not leave liquids or damp cloths on this furniture.

To avoid dulling of the finish, do not place furniture in direct sunlight. Please inspect and tighten all screws or bolts on a regular basis to ensure proper performance and safety of your item.









Required -Flathead screwdriver Phillips screwdriver Rubber mallet **Not Included**




NEED HELP? For help with assembly or if you are missing a part, Please call customer service






- 1. Insert 1 Dowel 3 into pre-drilled hole on each Top Divider C.
- 2. Use rubber mallet to tap Dowels (3) into bottom of holes securely. 1/2 length of Dowels should be exposed.
- 3. Attach 3 Top Dividers ©to Top Shelf (E) using 6 Allen Key Screws (1) (2 Screws on each Divider).
- 4. Use Allen Key 4 to tighten screws. Do not over-tighten.




- 1. Insert 1 Dowel (3) into pre-drilled hole on each Bottom Divider (D).
- 2. Use rubber mallet to tap Dowels (3) into bottom of holes securely. 1/2 length of Dowels should be exposed.
- 3. Attach 6 Cam Lock Pins 2 to Top Shelf E using guide holes.
- 4. Align Cam Lock Pins with pre-drilled holes on Bottom Dividers D.
- 5. Insert 2 Cam Locks 2 into pre-drilled holes on each Divider D.
- 6. Use flathead screwdriver secure Cam Locks.

STEP-3




1. Repeat Step-1 for the second Top Shelf (E).


STEP-4




1. Repeat Step-2 for the other three Bottom Dividers ①.




- 1. Insert 1 Dowel (3) into pre-drilled hole on each Bottom Divider (D.
- 2. Use rubber mallet to tap Dowels (3) into bottom of holes securely. 1/2 length of Dowels should be exposed.
- 3. Attach 3 Bottom Dividers ① to Bottom Shelf (F) using 6 Allen Key Screws ① (2 Screws on each Divider).
- 4. Use Allen Key 4) to tighten screws. Do not over-tighten.



- 1. Insert 8 Dowels 3 into pre-drilled holes on each Top Shelf (E) and Bottom Shelf (F) (4 dowels on each shelf).
- 2. Use rubber mallet to tap Dowels (3) into bottom of holes securely. 1/2 length of Dowels should be exposed.
- 3. Attach 9 Cam Lock Pins (2) to each Side (B) using guide holes.
- 4. Align Cam Lock Pins with pre-drilled holes on Top Shelfs (E) and Bottom Shelf (F).
- 5. Insert 6 Cam Locks 2 into pre-drilled holes on each Top Shelf E and Bottom Shelf F (3 Cam Locks on each side of shelf).
- 6. Use flathead screwdriver secure Cam Locks.




- 1. Attach Top (A) to Sides (B) and 3 Top Dividers (C) using 15 Allen Key Screws (1) (3 screws on each Side and Divider).
- 2. Use Allen Key 3 to tighten Screws. Do not over-tighten.
- 3. Attach Bottom Support Leg (G) to Bottom Shelf (F) using 4 Phillips Screws (6)
- 4. Use Phillips screwdriver to snugly tighten screw.



- 1. Attach Back Panels (H) to back frame of cube storage using 44 Phillips Screws Round Head (5) through pre-drilled holes.
- 2. Use Phillips Screwdriver to tighten screws.

NOTE: Injuries and damage can occur from furniture tip-over. It is important to use the safety bracket included. If the tipping restraint kit is not in the box, please contact our customer service department in order to obtain another kit before using the furniture.



When you determined the location for your unit, install the Furniture Tipping restraint. Carefully follow the instructions contained on the package.

WARRANTY

Thank you for purchasing a product. These products have been made to demanding, high-quality standards and are guaranteed for domestic use against manufacturing faults for a period of 12 months from the date of purchase. This warranty does not affect your statutory rights.

In case of any malfunction of your product (failure, missing parts, etc.) please contact us at our toll free service line or by email

We reserve the right to repair or replace the defective product, at its discretion.

This product is guaranteed for 12 months if used for normal purposes. Any warranty is invalid if the product has been overloaded or subject to neglect, improper use or an attempted repair by other than an authorized agent. Heavy-duty or daily professional/commercial usage are not guaranteed.

Due to continuous product improvement, we reserve the right to change the product specifications without prior notice.