



Calculating how much flooring you need is easy! Follow our tips below to figure out the proper amount you will need for your space.

The Central Area:



- Measure your room's length and width, creating a square or rectangular perimeter.
- Multiply the length by the width to get your square footage. (A 15-foot wide and 15-foot long room will need enough flooring for 225 square feet.)

Irregular Areas:



- Measure the spaces that fall out of the rectangle you measured above separately and calculate that square footage the same way.
- Add that measurement to your main area measurement to get the total area of your room.

Tip: When in doubt, round up. It is always better to have extra on hand!

Keep in Mind:

There will be some leftover flooring that won't be used due to the shape of a room. With our guide below, calculate this additional amount and add it to the area of your room.

- **Hardwood:** Add 5% of extra flooring.
- **Hardwood on a Diagonal:** Add 15% of extra flooring.
- **Laminate:** Add 10% of extra flooring.
- **Tile:** Add 20% of extra flooring.