

Please insert the top of the lower pole section into the bottom of the upper (canopy) pole section and lock in place using the button near the top of the bottom pole section as shown in diagram #1. For maximum strength, please snap lower pole connector button into the second button hole of the upper pole section in your assembly as per diagram #1.

