









4 Drawer Chest

Assembly Instructions






HARDWARE

A	B	C	D	E	F	G
						
Ø6x32mm	Ø15x9mm	Ø8x30mm	Ø4.0x30mm	Ø3.5x12mm		ø4x12mm
36x	36x	26x	16x	54x	8x	8x
H	I	J	K	L	M	N
						
ø7x30mm	Handle	Ø4x22mm			Allen Key	
3x	8x	8x	2x	2x	1x	4x

PARTS



Safety Advice

Please take the time to carefully read through the whole of these instructions before you commence.

Keep these instructions for future reference.

Unpack, inspect and check off all of the contents.

Please dispose of all packaging safely.

Small component parts could choke a child if swallowed.

We strongly recommend that you keep children well away from the work area.


It would be sensible to lay a sheet or blanket on the floor where you intend to work to avoid scratching this product and to protect your floor.





This product is heavy. Take extreme care when lifting to avoid personal injury or damage to the product.

Assemble the product as close to its intended final position in the room as possible.

HANDY HINT: If you keep the hardware in a bowl during assembly you will be less likely to lose them.

1



Ax14	
Fx8	
Ex16	




Do Not Use Power Tools

2


Bx7	
Cx7	





Do Not Use Power Tools




3


Bx7 	Nx4 
Cx7 	





Do Not Use Power Tools



4

Ax6 



Do Not Use Power Tools

5

Bx6





Cx4



Hx3






Mx1




6


Ex36



7


Ax16 	Bx16 	Cx8 
Dx16 	Jx8 	Ix8 

x4



8

Gx8 	Ex2 
Kx2 	
Lx2 	




9

ADDITIONAL SAFETY INFORMATION

In the interest of safety, particularly where small children are concerned, we advise securing your furniture to the wall to prevent the product from tipping forwards when loaded.

The screw included in this fitting pack is only intended for fixing the safety strap to the piece of furniture.

Use fixing devices suitable for the walls in your home,(NOT INCLUDED).
If you are unsure what type of fixings to use, please seek further advice from your local DIY store.



Your 4 Drawer Chest is now ready for use.

General Care

Wipe clean with a slightly damp soft cloth.

Avoid the use of all household cleaners and abrasives.

When moving your furniture, carefully lift into place.

Never drag or push the pieces across the floor as this will cause damage to the joints and could result in failure to the product that will invalidate the warranty.

Recommendations

Periodical re-tightening of fixings.

Warning

This unit is heavy. Please use an assistant when lifting.

Notes

We've tried to make this piece of furniture as easy to assemble as possible. In the unlikely event that you have problems putting it together or have damaged or missing pieces, please contact our customer services