


Assembly Instruction Sheet for Model HL579197

Package Contents

Part	Description	Quantity
A	Mounting Bracket	1 pc.
B	Large Arm Support Plate	1 pc.
C	Fixture Arm	multi pcs.
D	Central Column	multi pcs.
E	Decorative Antler	multi pcs.
F	Small Arm Support Plate	multi pcs.
G	Chain	1 pc.
H	Canopy	1 pc.



STEP 1

Mark the drilling position on ceiling with the help of the Mounting Bracket(A).
Drill holes on the marks and stick the expansion anchors into the holes.
Fix the Mounting Bracket(A) to the expansion anchors with self-tapping screws.

STEP 2

Remove the chassis of Large Arm Support Plate(B).
Thread the wire of Fixture Arm(C) to the Large Arm Support Plate(B),
and screw the Fixture Arm(C) to the Large Arm Support Plate(B).
Repeat the above step to fix the other Fixture Arms(C).

STEP 3

Connect wire color Blue/Red from the Arm Support Plate(B) as one strand of wire.
Connect wire color Black/White of Arm Support Plate(B) as the other strand.
Restore the chassis to the Large Arm Support Plate(B).

STEP 4

Thread the wire of Large Arm Support Plate(B) to the Central Column(D),
and fix the Central Column(D) to the Arm Support Plate(B).

STEP 5

Fix the Decorative Antler(E) to the Small Arm Support Plate(F).
Repeat the above step to fix the other Decorative Antler(E).

STEP 6

Thread the wire from the Central Column(D) to the Chain(G), and fix the Chain(G) to the Central Column(D).
Thread the wire of Chain(G) to the Canopy(H), and attach the Chain(E) to the Canopy(H).

STEP 7

Hold the fixture close to ceiling.
Connect live line to wire color Blue/Red from the Canopy(H).
Connect neutral line to wire color White/Black from the Canopy(H).

STEP 8

Attach the Canopy(H) to the Mounting Bracket(A).

STEP 9

Install your bulb to the bulb base of Fixture Arm(C).

Your fixture is now assembled and ready to use.