






Installation & Assembly





WE'RE HERE IF YOU NEED IT CONTACT US

If you encounter any difficulties during assembly, or notice damaged packaging, missing components, or damaged parts, please do not rush to return the product. Instead, refer to the parts list to find the required part numbers, and feel free to contact our seller support team on the e-commerce platform where you made the purchase for professional assistance.

WE CARE ABOUT YOUR SAFETY PLEASE READ

IMPORTANT SAFETY NOTICE READ CAREFULLY BEFORE BEGINNING ASSEMBLY

This unit contains small parts that present a choking hazard for children under 3 years of age. These parts are for adult assembly only and should be permanently affixed to the furniture. Any unused parts should be discarded properly. To make the assembly process easier, ask a friend to help you.

2 people required

Always use proper tools.

Carefully review the parts and hardware list.

Follow assembly steps in order. DO NOT SKIP ANY STEPS.

Periodically check to ensure that all connectors (bolts, screws, etc.) are tight.





Keep the instructions for future reference.

It is recommended that you assemble the unit on a protected surface or carpeted floor to avoid scratches.


Our Company disclaims any liability for damages or injuries

which may occur due to failure to properly follow assembly instructions, properly assemble the product, or properly use the product.

⚠ WARNING	
	Children have died from furniture tipover. To reduce the risk of furniture tipover: • ALWAYS install tipover restraint provided. • NEVER put a TV on this product. • NEVER allow children to stand, climb or hang on drawers, doors, or shelves. • NEVER open more than one drawer at a time. • Place heaviest items in the lowest drawers. <i>This is a permanent label. Do not remove!</i>
	


A	x39	B	x39	C	x18	D	x4	E	x1	F	x34	G	x20	H	x8	I	x2
																	
M6*35mm		Ø15*9.5mm		Ø6*30mm		M7*60mm		M4		M3.5*14mm		M4*35mm					
J	x2	K	x6	L	x1	CL	x3	CR	x3	DR	x3	DL	x3				
																	
		30*10*5mm				300mm		300mm		300mm		300mm					


1




A	x4	F	x2	J	x2
					
M6*35mm		M3.5*14mm			

2



A	x6	C	x6	F	x12	CL	x3	CR	x3
									
M6*35mm		Ø6*30mm		M3.5*14mm		300mm		300mm	


3



B	x3
	
Ø15*9.5mm	

4

Align the holes on board 3 and board 4 horizontally.




B	x3
---	----



Ø15*9.5mm

5




C	x4
---	----



Ø6*30mm

6

Align the grooves on board No. 1 carefully.




B

x4




Ø15*9.5mm

7




L

x1




8




C	x4	D	x4	E	x1
					
Ø6*30mm		M7*60mm		M4	

9




A	x10
	
M6*35mm	

10




A	x4	C	x4
			
M6*35mm		Ø6*30mm	

11



B	x4
	
Ø15*9.5mm	

12




B x10



Ø15*9.5mm

13




K x6




30*10*5mm

14




This step is critical—do not skip. Correctly install the back panel latch as shown in the diagram.



H	x8	F	x8
	M3.5*14mm		

15


The round hole on board No. 15 faces downward.



Make sure the grooves on boards 11, 12, and 13 are aligned.


G	x18
M4*35mm	

16



x3


17



x3


A	x15
M6*35mm	

18



B	x15
	
Ø15*9.5mm	



19



F	x12	DR	x3	DL	x3
					
M3.5*14mm		300mm		300mm	


20

WALL



I	x2	G	x2
			
		M4*35mm	

21



Tilting the drawer during insertion makes installation easier. Forced straight push may damage slides.