

## **INSTRUCTION MANUAL** MODEL: 1387-2GSM

Edition:20240418580Z


## **ASSEMBLY GUIDE**

Congratulations, you now have a new function sofa with massage.


Before enjoy the comfort chair, you have to put it together. This Assembly Guide will take you through the basic assembly process. To make sure your assembly goes smoothly, please follow the assembly instructions, **and especially the important safety information**.


Also, while it is possible to assemble the chair on your own, <u>having a</u> <u>second person to help you makes it even easier.</u>


Before you begin, please check if there are any missing parts from the package. Should there be any issues, please don't hesitate to drop us an email and we'll help you out ASAP.




1.Insert individual components into D-6 and then insert D-7.









2.Bury the nut in the corresponding position and secure the screw on the handrail with a wrench.



#### 05


#### 3.Cover the handrail on the assembled handrail and zip it up.






80

4.Insert arms so that they can fit into the seat, you will hear a "click" when they are engaged.




5.Pull the handle up to expand the footrest, cover the cushion, stick the three Velcro.


09




6.Plug the back pad into the seat frame, and then connect the massager line white and white, red and red, black and powerlines, and the massage line with the hand controller.



7.Insert the back ear so that it can be installed into the back side. When they engage, you will hear a "click" sound.




8.Stick the lower back curtain from the rear frame to the seat frame.




# 

Pull the handle to spread out the SOFA




Pull back the SOFA with your legs

## Congratulations!You've assembled Your sofa!



Note: Since the Sitting mat is packed in compression, after the product is installed, you need to tap and adjust the backrest which can help restore fullness. After two days, you will get a Overstuffed Recliners as picture shows.



#### $I\,\,{\scriptstyle \backsim}$ Specifications of power adapter

Connect the adapter plug to the power cord socket of the center box, and then insert the adapter into the 220V output socket. Power adapter specifications: Input: AC 100-240VAC, 50/60Hz; Output: DC12V, 1.5A.

- $II \searrow \mbox{Product features}$
- 1、4 parts 8 motor vibration
- 2、1 heating plate
- 3、Supports USB charging 5V 2.0A
- 4、3-segment timed shutdown duration selection
- 5、 Selection of 3rd gear vibration intensity
- 6、 5 vibration modes selection
- 7、 Default scheduled shutdown time 10Min

#### III、Function details

- Vibration on key: Click to turn on the vibration function, then click again to turn off the vibration function (cycle);
- 2、Vibration intensity key: Press and cycle to switch vibration intensity. When turned on, the default mode is M (middle),  $M \rightarrow H \rightarrow L$  (cycle);
- 3. Timed shutdown button: Press and cycle to switch the timed shutdown time. The default time for powering on is 10 minutes;  $10min \rightarrow 20min \rightarrow 30min$  (cycle);
- 4、Heating on key: Click to turn on the heating function of the heating plate, and then click again to turn off the heating function of the heating plate (cycle);
- 5、Vibration mode key: Click on cycle to switch vibration mode. The default mode for startup is M4 M4  $\rightarrow$  M5  $\rightarrow$  M1  $\rightarrow$  M2  $\rightarrow$  M3 (cycle);
- 6、Vibration positioning key: Click to select the vibration location.

### 15

#### 16

#### Warnings

- Sit down in the chair gently. To avoid tipping over, do not throw yourself into the chair. Move the chair into the reclining position slowly, making sure that no children or pets are in close proximity. Do not allow children to play on or around the chair, particularly when it is in an open position.
- Close the recliner completely before getting out of it.
- Never sit on the footrest when it is open, even if it is a child.
- To eliminate the risk of tipping over, do not sit on the arms or footrest of the chair.
- This chair is designed to be used by 1 adult at a time.
- Please forbid people with the following ailments from using this sofa: Those people with severe symptoms of heart disease, high blood pressure, cerebral thrombosis and others who are sensitive to heat or completely insensitive to heat, those with brittle bones or have issues with waist support pregnant women, children and others where it has been determined they are not suitable to use this product under the guidance of doctors.
- To fully recline the sofa, ensure the sofa well, you need to put the sofa at least 19 inches away from the wall or any other obstacle.
- Product cannot touch water, fire, etc. Product can also not come in contact with sharp objects (knives, nails, etc.)

#### **Maintenance Manual Instructions**

- To avoid dropping, you should carry the sofa carefully.
- If you find dirt and or stains on the chair, spray the sofa with a sofa specific cleaner then use a sponge or cloth to wipe the dirt away. Do not use water, soapy water or cleaner with waxed wooden areas. Take care to wipe the sofa carefully and gently.
- Do not put the sofa in an area with direct sunlight and do not put the sofa directly in front of an air conditioner, this will fade the upholstery and make it brittle.