



ASSEMBLY INSTRUCTIONS

1. FASTEN SOCKET ASSEMBLY (B) SECURELY ONTO BASE (A). BE CAREFUL NOT TO TWIST THE POWER CORD. TIGHTEN SECURELY.
2. PLACE HARP (C) ONTO SADDLE. PLACE SHADE (D) ONTO THE HARP (C).
3. TIGHTEN FINIAL (E).

CLEANING

DO NOT USE POLISH OR CLEANERS ON YOUR LAMP, JUST WIPE CLEAN WITH SOFT CLOTH.

WARNING

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER). AS A FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK, THIS PLUG WILL FIT IN A POLARIZED OUTLET ONE WAY ONLY. IF IT DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS THE PLUG CAN BE FULLY INSERTED.

DIRECTIVES D'ASSEMBLAGE

1. BIEN FIXER LA DOUILLE (B) SUR LE BASE DE LAMPE AVEC USB (A). FAIRE ATTENTION DE NE PAS TORSIONNER LE CORDON D'ALIMENTATION. SERRER SÛREMENT.

NETTOYAGE

NE PAS UTILISER DE POLISH NI DE PRODUITS DE NETTOYAGE SUR LA LAMPRE, SEULEMENT AVEC UN CHIFFON DOUX ET PROPRE.

AVERTISSEMENT

CETTE LAMPRE PORTABLE A UN BOÎTIER EN PLASTIQUE ET UN CORDON D'ALIMENTATION POLARISÉ (UNE LAME EST PLUS LARGE QUE L'AUTRE). EN VUE DE RÉDUIRE LE RISQUE DE CHOC ÉLECTRIQUE, CE BOÎTIER NE PEUT ÊTRE INSÉRÉ DANS UNE PRISE POLARISÉE QUE D'UNE SEULE MANIÈRE. SI LE BOÎTIER NE PEUT ÊTRE INSÉRÉ DANS LA PRISE, INVERSEZ LE BOÎTIER. SI LE BOÎTIER NE PEUT ÊTRE INSÉRÉ, CONTACTEZ UN ÉLECTRICIEN QUALIFIÉ. NE PAS UTILISER AVEC UN CORDON D'EXTENSION SAUF SI LE BOÎTIER PEUT ÊTRE INSÉRÉ COMPLÈTEMENT DANS LA PRISE.