



Large 6.5 meters wide/Small 4.5 meters wide
Racing Demon Spider

AFTER-SALES SERVICE

Our team always stands behind its products. Customers' satisfaction is our pursuance, forever.

If the item received damaged, Missing of the accessory, Difficult to install, Or just you don't like it. Please contact us by email. We are always ready to service you and help you.

Our team always stands behind its products. Customers' satisfaction is our pursuance, forever.

 WARNING


- 1.This is a seasonal decoration and is not intended for permanent installation or year-round use. It is recommended not to use it for more than 90 consecutive days.
- 2.Do not attempt to inflate during unusually strong winds. If it becomes too windy for safe operation, simply allow your inflatable to deflate. Secure it and wait for better conditions before re-inflating.
- 3.This is an electric product, not a toy. Keep the product out of the reach of children to avoid any accidents or electrical shocks.
- 4.Protect the electric fan and power cord from exposure to water. This precaution will reduce the risk of electrical shock.
- 5.Do not use anything with this product that is not included in the original manufacturer's packaging when purchased.
- 6.Do not expose the product to sharp items, as these may cause rupture and damage.
- 7.Do not hang ornaments or other objects.
- 8.Do not close the door or window onto the power cord or extension cords, as this may damage the product's wire insulation.
- 9.Do not secure the wiring or the product with staples, nails, or other sharp objects, or place wiring on sharp hooks or nails.
- 10.Only a qualified technician is allowed to repair the damaged main connection cable.
- 11.When the temperature is below 5°F (-15°C), the motor may temporarily stop running. The motor will begin functioning again at higher temperatures.

 CAUTION

- 1.Do not wipe the motor clean.
- 2.To protect the service life of the blower, please inflate the product for no more than 12 continuous hours.
- 3.Periodically unplug the product from the electrical outlet to allow the transformer and fan to cool down to avoid overheating and/or product damage.
- 4.Neatly fold and store the product in a cool, dry location away from sunlight or heat sources.
- 5.Unplug, roll up, and store in the original package or a similar size box.
- 6.Periodically check to ensure there are no holes or tears in the inflatable figure. If you find any tears in the fabric, you can repair them with a needle and regular thread. No special thread is necessary.
- 7.Only use mild detergent with cold water and use a soft damp cloth to wipe clean the figure.

STEP 1

- 1.When the product is taken out, please ensure that other accessories are not dropped on the ground as this may cause them to be lost or not used.
- 2.Place the inflatable in a clean, open area free from debris or other obstructions.
- 3.Make sure the air intake located on the bottom of the unit is clear of fabric and free of obstruction.



STEP 2

Place a sandbag, water bag or other heavy object directly in front of the internal unit. Ensure that the zipper is fully closed.



STEP 3

Fully unfold the product before inflation, then plug it into a waterproof power outlet.



STEP 4

Using the clip on the end of the tether, attach the clip to a ring grommet on the side of the inflatable.




STEP 5

Secure the plastic stakes into the ground at an angle and attach the nylon tethers.



STEP 6



ADAPTOR INPUT
100-240V, 50/60HZ

CAUTION:

- 1.This inflatable has a plug that will fit into a polarized outlet only one way.
- 2.This is a safety feature.
- 3.If you are unable to insert the plug into the electrical outlet, try reversing the plug.
- 4.If the plug still does not fit, contact a qualified electrician.
- 5.Never use the plug with an extension cord unless you can fully insert the plug into the extension cord.
- 6.Do not alter the plug, and do not attempt to defeat the safety purpose of the polarized plug.



Within 1-2 mins, this lighted inflatable will fully inflate. If not, check if the fan vent is blocked by fabric.