ASSEMBLY INSTRUCTIONS




TOOLS REQUIRED



Allen Wrench



2 - People Recommended



EASY DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.

Thank you for your purchase!

We hope you enjoy this new addition to your home for many years to come.

Our commitment to providing quality products does not simply end when you purchase our product. We fully stand behind our products from start to finish. To help expedite our service, please have these assembly instructions readily available, along with your order receipt.



Are you missing anything?

Double-check all parts, hardware and accessories listed on Page 6 are accounted for.



Are there any irregularities or flaws in the parts? We can send replacements!

Check out our Quick Tips!

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

Prep Time!


Please review the assembly instructions and all diagrams prior to assembling. Arrange parts as recommended on Page 7 and group identical hardware together to make assembling easier.

PRE ASSEMBLY

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.
















Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.

Suitable Location

Assembling near the area of the intended location is highly recommended.

Sufficient Space

Make sure you have enough space to move around during the assembly.

Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.


Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE




FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.




IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.






Allen Wrench 4mm


Exploded View




ASSEMBLY INSTRUCTIONS









 Check the quantity and irregularity of parts and hardware before you start.



	PARTS	
#1 1pc x4	#2 1pc x4	#3 2pcs x4
Chair Back	Cushion Seat	Front Leg
	HARDWARE	
#A 4pcs x4	#B 4pcs x4	#C 2pcs x4
Bolt Ø1/4" x 3"	Bolt Ø1/4" x 2-3/8"	Bolt Ø1/4" x 1-1/2"
#D 10pcs x4	#E 10pcs x4	#F 1pc x4
\bigcirc		
Lock Washer Ø1/4"	Flat Washer Ø1/4"x19mm	Allen Wrench 4mm



ASSEMBLY INSTRUCTIONS



ASSEMBLY INSTRUCTIONS

3

4

Part (#3) × 2pcs Hardware (#B) × 4pcs Hardware (#D) × 4pcs Hardware (#E) × 4pcs

