











ASSEMBLY INSTRUCTIONS

WF304181/82/87


SINGLE SOFA












SINGLE SOFA is packed in 3 cases

Carton	Disignation	Part	Hardware
1/3 WF304181	Backrest	#1 	
	Riser plate	#2 	
	Former board	#3 	
2/3 WF304182	Cushion	#4 	#A #B #C #D
	Pillow	#5 	
	Leg	#6 	
	Support leg	#7 	
3/3 WF304187	Left arm	#8 	
	Right arm	#9 	

ASSEMBLY INSTRUCTIONS



PARTS


#1 1pc	#2 1pc	#3 1pc	#4 1pc	#5 1pc
				
BACKREST	RISER PLATE 555*555MM	FORMER BOARD	CUSHION	PILLOW
#6 4pcs	#7 2pcs	#8 1pc	#9 1pc	
				
LEG	SUPPORT LEG 30*30*255MM	LEFT ARM	RIGHT ARM	

HARDWARE


#A 12 pcs	#B 1 pc	#C 12 pcs	#D 12 pcs
			
BOLT 1-1/2" L	ALLEN KEY 4mm L	SPRING WASHER	FLAT WASHER 16mm

ASSEMBLY INSTRUCTIONS

STEP 1:




STEP 2:




ASSEMBLY INSTRUCTIONS

STEP3:




STEP4:




ASSEMBLY INSTRUCTIONS

STEP5:



STEP6:



ASSEMBLY INSTRUCTIONS

STEP 7:

