














	PARTS LIST	DESCRIPTION	QTY		PARTS LIST	DESCRIPTION	QTY
A		SEAT FRAME	1	E		1/4"x30 mm BOLT	14
B		BACK FRAME	1	F		Ø6.5x1.0 mm WASHER	28
C		ARM RIGHT	1	G		1/4" NUT	14
D		CORNER BACK FRAME	1	H		10 / 12mm HEX WRENCH	1
				I		HEX BOLT DRIVER	1



	PARTS LIST	DESCRIPTION	QTY		PARTS LIST	DESCRIPTION	QTY
A		TOP PANEL	1		D 	1/4"x40 mm BOLT	18
B		LEG	2		E 	Ø6.5x1.0 mm WASHER	18
C		SIDE PANEL	2		F 	HEX BOLT DRIVER	1



	PARTS LIST	DESCRIPTION	QTY			PARTS LIST	DESCRIPTION	QTY
A		SEAT FRAME	1		E		Ø6.5x1.0 mm WASHER	22
B		BACK FRAME	1		F		1/4" NUT	11
C		ARM LEFT	1		G		10 / 12mm HEX WRENCH	1
D		1/4"x30 mm BOLT	11		H		HEX BOLT DRIVER	1