


# Installation Diagram



## Installation Instructions

1. Power supply: AC 110-240V, 50Hz/60Hz
2. Instructions for use:
  - Installation and maintenance must be carried out by qualified technicians.
  - Please turn off the power before replacing the light bulb.

## Precautions

1. Please wear cotton gloves when installing the lamp body.
2. Always disconnect the power supply before installation. Ensure safety first, then install according to the provided instructions.