






















1		x1
2		x1
3		x2
4		x1
5		x2
6		x1
7		x2
8		x1
9		x1
10		x1
11		x3
12		x2
13		x1
14		x1
15		x2
16		x1


17		x2
18		x1
19		x1
20		x1
21		x1
22		x1
23		x2
24		x1
25		x1
26		x3
27		x1

A	M6x40 	x4
B	M5x35 	x2
C	M6x25 	x4
D	M6x16 	x6
E	M6x12 	x6
F	M5x16 	x12
G	M5x12 	x8
H	M8 	x2
I	M6 	x6
J	M5 	x24
K	Ø6x16 	x14
L	Ø5x12 	x2
M	M6x20 	x2


1




2




3





4




5




6




7




8



9



10




以上为标准配置，我们还有如下两种选择。


The above is the standard configuration, we also have the following two options.

选择一：电动旋转马达烤枝

Option 1: Electric rotary motor baking support




不可调节



选择二：手动摇杆烤枝

Option 2: Manual joystick baking support



三档调节

