




12257S_15632 SERIES SMARTLITE® SWEEPER ALARM CLOCK

Thank you for your purchase of this quality clock. Please read these instructions and keep them in a safe place for future reference.



1. Time set knob.
2. Alarm set knob
3. Alarm on/off switch.
4. Light/Snooze button.
5. Smartlite® sensor.
6. Smartlite® sensor on/off switch.

TO INSTALL/REPLACE BATTERIES

Remove the battery compartment cover and insert 3XAA batteries observing the polarity markings inside the compartment. Replace the cover.

TO SET THE TIME

Turn the 'Time set knob' in the direction of the arrow to set the hour and minute hands to the correct time.

TO SET THE ALARM

Turn the 'Alarm set knob' in the direction of the arrow to the desired wake up time.

TO TURN ON/OFF ALARM

Slide the switch to AL.ON or AL.OFF.

LIGHT/SNOOZE

Press the 'Light/Snooze button' to light the dial.

To activate snooze during the alarm, press the 'Light/Snooze button' - after which alarm will sound again approximately 4 - 8 minutes later.

SMARTLITE®

This clock incorporates an innovative new technology called "SMARTLITE®". Slide the "Smartlite® sensor switch" to ON position, the dial will stay illuminated in dark conditions or when sensor is covered, until you slide the "Smartlite® sensor switch" to the OFF position. The Smartlite® sensor also automatically turns off the dial illumination in bright conditions to prolong battery life. The Smartlite® feature may be used up to 8 hours per day with battery life of approximately 12 months.

CHANGING BATTERIES & MAINTENANCE

It is recommended that you replace the batteries annually even if the product is still running. Only use 3 X AA (1.5V) Alkaline batteries in this clock. Do not mix new or used batteries, different types or brands. Remove the batteries if the clock is stored or not in use. Remove exhausted batteries from the product.

Warning: Do not recharge non-rechargeable batteries.

Please dispose of used batteries in a responsible manner. For more information please contact your local authority.

A soft cloth may be used to clean your clock. Do not use any corrosive cleaner or chemical solutions on the clock. Keep the clock clean and dry to avoid any problems.

YOUR GUARANTEE

Your clock is guaranteed for 24 months from the date of purchase against any faults arising from defective materials or manufacture. Damage caused through careless handling, misuse or in transit is expressly excluded. Should this clock fail within 24 months please return it in the first instance to your retailer.

Environmental Protection

Disposal of electrical & electronic equipment



Do not dispose of this product with household waste. For the proper treatment, recovery and recycling please take this product to the appropriate collection point. If you are unsure of where this is contact your local authority. Improper disposal may be harmful to the environment.



For more innovative Acctim products please visit: www.acctim.com