

INSTRUCTION MANUAL



9 Ft. Patio Table Umbrella With Tilt and Crank

! CARE & MAINTENANCE

- △ Clean with lukewarm water, mild detergent & Sponge.
- △ Wipe down aluminum pole with damp cloth.
- △ Store in a location when not in use.


! SAFETY PRECAUTIONS

- △ Store the umbrella in windy or stormy weather.
- △ Be aware that some parts are heavy and have sharp edges.
- △ Do not use or store this item in the proximity of open flame or flammable/combustible chemicals.
- △ Do not allow umbrella to flap in the wind as it may cause damage.
- △ When adjusting umbrella, make sure no person or item is close to umbrella to avoid injury or damage.

PARTS

A

UMBRELLA BODY



1 PC

B

EXTEND POLE



1 PC


PRODUCT ASSEMBLY

1

Check the status of umbrella before your assembly.

Plug part A Umbrella Body carefully into part B Extend Pole.


△ Pay attention that the spring bracket on the end of Umbrella Pole is fixed into the small hole at the end of part B Extend Pole after you hear "KA" sound.



2

Insert part B the Extend Pole into the Umbrella Base or the fixing tube on the Table.


Tighten the bolt to fix the Extend pole.



PRODUCT ASSEMBLY

3

Loose the umbrella cloth belt before you open the umbrella.



4

Turn the crank clockwise to open the umbrella while turn anti-clockwise to close the umbrella.

The angle of this umbrella can be easily adjusted by hand for more sunshade area.

Push the silver button shown as below and tilt the umbrella to left or right by a max degree of about 30°.

△ Hold the umbrella when tilting to avoid any injury or damage.

