

# ADULT ASSEMBLY REQUIRED

Attaching Wood Table Legs

**BIRD•IN•HAND**

**Woodworks, Inc.**

Lancaster, Pennsylvania

A member of the School Specialty Family

## Product Guide - General Instructions and Information

### Customer Service:

P.O. Box 1579

Appleton, WI 54912-1579

Phone: 1-888-388-3224

Customer Care Website:

<https://help.schoolspecialty.com/s/>

### Warning:

This product is for children.

Supervision is required at all times.

### Warning:

Manufacturer is not responsible for modifications made to our products by customers.

### Cleaning:

Use a mild soap and water solution. Be sure to wipe all water from the wood surface.

### Important:

Do not discard these instructions. Keep for future reference.

### Attach the table legs as follows:

1. Place table leg against table aprons so that the hanger bolt extends through the leg bracket.
2. Place a flat washer followed by a lock nut over the hanger bolt.
3. Using a 1/2" wrench or socket, turn the lock nut clockwise to thread it onto the hanger bolt.
4. Finish tightening the nut until the leg is tight in the corner.
5. Repeat for the remaining three legs.

### REPLACEMENT PARTS:

Part #	Qty.	Description
407059	1	12" leg
407017	1	14" leg
407275	1	16" leg
407122	1	18" Leg
407116	1	20" Leg
407119	1	22" Leg
407020	1	24" Leg
407096	1	26" Leg
407105	1	28" Leg
407110	1	30" Leg

### USE THE CHART BELOW TO ORDER OTHER TABLE LEG SETS:

#1386529 - 12" Legs

# 271744 - 14" Legs

#1386530 - 16" Legs

# 267087 - 18" Legs

# 386605 - 20" Legs


# 267084 - 22" Legs

# 267085 - 24" Legs

# 267086 - 26" Legs

# 267089 - 28" Legs

# 267088 - 30" Legs



**IMPORTANT:** Do not use the hardware supplied with the table top (if included). Use only the hardware supplied with the table legs.

