

10 x 12 Ft Arc Top Gazebo with mosquito netting

WE HAVE YOU IN MIND, LET US SERVE YOU!

Safety Information

Two people are required for this assembly. Some parts may contain sharp edges.

Wear protective gloves.

When assembling and using this product, basic safety precautions should always be followed to reduce the risk of personal injury and damage to equipment. Please read all instructions before assembly and usage.



CAUTION: Do not climb on top of the gazebo. Falling off the gazebo can result in serious injury.

NOTICE: For outdoor use



DANGER: This unit is heavy! Do not assemble this item alone



WARNING: Do not leave the gazebo where there is a risk of high wind, as possible damage will occur to the structure.




WARNING: Keep all flame and heat sources away from this gazebo fabric. This Gazebo is made with fabric that meets CPAI-84 specifications for flame resistance. It is not fire proof. The fabric will burn if left in continuous contact with any flame source. The application of any foreign substance to the gazebo fabric may render the flame-resistant properties ineffective.

Parts Name	Item No.	Parts Images	Qty.
Upper Post	A1	(C.)	4
Lower Post	A2	·	4
Short Beam C1	C1		2
Short Beam C2	C2		2
Long Beam	D1		4
Middle Beam	D3		2
Upper Long Middle Top Bar	H1		2
Lower Long Middle Top Bar	Н2		2
Upper Short Middle Top Bar	I1		2
Lower Short Middle Top Bar	12		2
Upper Top Slant Bar	G1		4
Lower Top Slant Bar	G2		4
Top Connector	Ј		1

Parts Name	Item No.	Parts Images	Qty.
Side Curtain Bar	E1		4
Middle Curtain Bar	E2	10	2
Long Extension Tube	K1	500	4
Short Extension Tube	K2		4
Big Canopy	01		1
Small Canopy	02		1
Mosquito Netting	P1		4
Screws DD	ВВ	M6×18mm	24
Stake	II		8
Ring	LL		36
Hook	N		1
Sandbags			4











Please find 2 PCS of D1 and assemble them into each end of D3 by using Screws BB.

This will be the Beam. We have to prepare 2 sets of beams first.














Attention: the Hook(N) should be under the $Top\ Connector(J)$.





























Care and Maintenance

Our steel components for garden accessories and furniture are treated with rust inhibiting paint that protects it from rusting. However, due to the nature of steel, surface oxidation (rusting) will occur once these protective coatings are scratched. This is not a defect and thus not covered by the warranty.

To minimize this condition, we recommend care when assembling & handling the product to prevent scratching the paint. Should any scratching or damage occur, we recommend immediate touch-up with rust inhibiting paint.


Surface rust can also be easily removed with a very light application of common cooking oil. If surface oxidation (rusting) occurs and if no measure is taken to prevent this, the oxidation may start dripping on to deck or patio and caused damaging stains, which may be difficult to remove. This can be prevented if the above-mentioned measures are taken to keep the product from oxidizing.

Use damp cloth to wipe off the stains as quickly as possible.

If necessary, wash with a mild solution of soap and water; rinse thoroughly and dry completely.

Periodically check and ensure that all bolts are well-tighten during use

THE WIND SNOW WEATHER





Please remove the canopy in snowstorm and gale days to avoid unnecessary damage to the gazebo

Thanks so much for your purchasing, and hope you will have a pretty

good experience both on assembly and daily using.

If any questions, please contact us

superlifeservice@163.com