

■ Dining Chair

ASSEMBLY INSTRUCTION



Dear customer, Thank you very much for buying our items. Please read the assembly instruction carefully before assembly.

Notices:

- Verify that all parts are present and in good condition before assembly.
- Put the chair on a clean flat surface.
- Please tighten the screws to about 80% for the first step; Then, sit with caution on the chair to adjust the balance; Finally, tighten all the screws to 100%.
- If you find that is unlevel after assembly, you can use adjustable pegs to keep four legs level.

Contact us


If there are installation problems, damage, missing parts, or any questions and concerns, please contact the shop where you bought it so we can make things right.

If the product is damaged, please send the following information:


- Photos that show the reason for your claim/damage.
- Photos of the packaging (inside and outside).

Thank you very much for your support!


Package Contents




Cushion




Back




Front Legs



Back Legs



Washer



Lock Washer



Spanner



M8x25mm
SHORT Screws




M8x45mm
MEDIUM Screws



M8x65mm
LONG Screws

Step by Step Guide




As shown in the picture, remove all the accessories from under the seat (accessories include the screw pack and legs).

Step by Step Guide

1

Holes faces this direction !




Align the two front legs with the screw holes on each side of the backrest and tighten.

Please note that when attaching the front legs to the cushion, if the holes are not aligned correctly, the angle of the front legs will need to be adjusted.

Step by Step Guide





2



Install the rear legs and backrest.
Align the back legs with the holes in the backrest
using the screws (D) and tighten. Note that the
screws are tightened to 60-80% at this point.

Step by Step Guide

3







Snap the cushion into place as shown in the picture.

Align the back legs with the holes in the cushion using the screws (E) with washers (A), (B) and tighten. Align the front legs with the holes in the cushion using the screws (F) with washers (A), (B) and tighten.

Step by Step Guide

4



Put chair in the upright position and sit on it to press downwards on the seat pad. Ensuring that all legs touch the ground and chair is leveled. After confirming the chair is stable, tighten all screws(D、E、F)to 100%.