








Garden Bench

PACKAGE CONTENT



4x



4x



8x




8x




8x

1



Hand tighten bolts to 60% to prevent holes from not aligning for the following steps.
Failing to do so may result in disassembly to realign the holes.

2



Make sure all bolts are tightly fastened before the unit is used.