


# ASSEMBLY INSTRUCTIONS

DME-001/DME-006/DME-007/DME-008/DME-009



(1) Carefully remove all parts from the box and remove all plastic coverings from the lamp components.

(2) Place the lamp Base (F) on the floor.

(3) Carefully screw the Wood Tube(C,D,E) together, then screw the whole wood assembly tube onto Iron tube(B).

(4) Screw the Whole Assembly tube onto Lamp holder(A).

(5) Ease any excess cable through the hole at the side of the Base(F). Screw the whole assembly onto the Base(F).

(6) Screw the iron tube (G) onto the lamp holder (A), and lock the lamp shade (H) with finial (I). Make sure the whole lamp is straight.

(7) Screw the Bulb(J) into the Socket.

**Note:** Bulbs not included. Surya recommends using LED bulbs.

<b>CAUTION: TO REDUCE RISK OF FIRE.</b> USE <b>MAX</b> 2x40 WATT TYPE A  LAMP OR USE <b>MAXIMUM</b> 2x9 WATT SELF -BALL ASTED  LAMP OR LAMP ADAPTER. 120V 60Hz AC ONLY MADE IN CHINA E483651	<b>ATTENTION: AFIN DE RÉDUIRE LE RISQUE D'INCENDIE</b> UTILISER UNE <b>MAX</b> AMPOULE TYPE A  DE 2x40 WATTS OU UTILISER UNE <b>MAXIMUM</b> 2x9 WATTS AUTOBALLASTÉE  LAMPE OU LAMPE ADAPTATEEUR. 120V 60Hz C.A. SEULEMENT FABRIQUÉ EN CHINE E483651
--	---

## CAUTION: IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. Do not alter the plug.

NOTE : The drawing of the lamp body is for reference only.

Made in China

Dear Customer,

Thank you for purchasing this quality lamp. It has been manufactured to meet the highest quality standards. Please carefully read the following precautions before use:

- When unpacking and assembling, avoid pulling on the wire too forcefully to prevent disconnection.
- Use only the bulb and wattage specified in these instructions or as indicated on the label attached to the socket.
- Do not replace the bulb while the lamp is plugged into an electrical outlet.
- Avoid using the lamp outdoors, near water, or other liquids.
- Unplug the lamp from the outlet before cleaning or removing any parts.
- Use a soft cloth for cleaning. Avoid using chemicals or abrasive cleaners.
- Remove the cellophane cover from the shade before using the lamp.
- During shipment, the socket cover may have become loose. Before inserting the bulb, ensure the socket cover is securely in place.