

Assembly Instructions

Caution: You must read this before you proceed

Care & Maintenance



- Not for commercial use. For residential use only.



- Do not put hot items directly on furniture surface.



- Do not clean furniture with harsh cleansers or polish.



- To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.



- Children should not climb or jump on the furniture.



- Do not write on furniture without a padded barrier to protect the surface.



- To obtain the longest lifespan of outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and/or place under patio or awings.




- Stains may be removed with mild soap solution and damp cloth.



- Dust and pick-up spills using a clean, non-colored, lint-free cloth.

Please look in Carton Box for hardware packs

DINING TABLE









CAUTION: This DINING TABLE is NOT a TOY.



Keep your child / children at bay during the assembly process.

Whenever lifting or moving the DINING TABLE and to prevent any damage to it, two adults may be needed to execute these actions.

PART LIST (N776P466782)


Label	Picture	Description	QTY
A		Panel -1	2pcs
B		Panel -2	2pcs
C		Panel -3	1pc
D		Leg Frame	2pcs
E		Side Connect Bar	2pcs
F		Middle Connect Bar	1pc

HARDWARE LIST (N776P466782)

Label	Picture	Description	QTY
①		Bolt M6 x 35 mm	5
②		Bolt M6 x 55 mm	26
③		Flat Washer Ø14xM6x1mm	30
④		Spring Washer Ø12xM6x2mm	5
⑤		Wooden Dowel M8x30mm	25
⑥		Allen Wrench M4	1

ASSEMBLY PREPARATION

Before Beginning Assembly:



• Read instructions, cover to cover-



• Have 2 adults on hand for assembly-



• Do not assemble on flooring or carpet-




• Assemble on a clean non - marring surface (packing foam)-



• Save all packaging until finished-


ASSEMBLY PREPARATION

Overview



This DINING TABLE has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the DINING TABLE parts, the above picture is to help you put the various parts into perspective. Please read through the instructions herebelow to familiarise the parts and steps before assembly.

Step 1:







Unpack and place all parts on a clean, non-marring surface.

STEP 1:

5






24



With assistance from your adult partner, position the Wooden Dowels (5) into Side Connect Bars (E) and Middle Connect Bar (F) as shown above.

STEP 2:

2		15
3		15
6		1




With assistance from your adult partner, place the Panel -1 (A), Panel -2 (B), Panel -3 facing down then attach Side Connect Bars (E) and Middle Connect Bar (F) to Panel -1 (A), Panel -2 (B), Panel -3 (C) by using Bolts (②), Flat Washer (③) with Allen Wrench (⑥) as shown above.

Do not fully tighten the Bolts.

STEP 3:

1		4
2		10
3		14
4		4
6		1



With assistance from your adult partner, attach Leg Frames (D) to assembled frame in step 2 then


3.1 Attach the Leg Frames (D) to the Table Top by by using Bolts (②), Flat Washer (③), with Allen Wrench (⑥) as shown above.

3.2. Attach Side Connect Bars to the Leg Frames (D) by using Bolts (①),Flat Washer (③),Spring Washer (④) with Allen Wrench (⑥) as shown above.

Repeat this step to assemble another leg.

Do not fully tighten the Bolts.

STEP 4



Inspect it and make sure all parts are adequately connected.

Stand the Table up.

Exert pressure floorwards, onto the Table with both your hands.

This pressure will help the Legs and Table Top reach full alignment status.

Check for wobbles on a LEVEL surface.

If no wobbles are found proceed to tighten the Bolts and Screws in a sequential manner, until evenly secured.

When tightening the Bolts and Screws tighten sequentially.

Do not tighten any Bolt, Screws fully and then move on towards the next one.

If there are still wobbles, loosen the Bolts and Screws execute the same above process.

WARNING!! IF TABLE IS NOT STABLE, IT COULD LEAD TO DAMAGING THE PRODUCT.

Your Table is ready for use.

This Table can only be used on a flat, level surface.