


















Assembly Guide



READ AND SAVE THIS INSTRUCTIONS FOR FUTURE USE

ASSEMBLY & INSTRUCTION MANUAL


Ax1 	Bx1 	Cx1 	Dx1 
Ex1 	Fx1 	Gx2 	Hx2 
Ix2 	Jx1 	Kx3 	Lx3 
①x12+1  M3*16mm	②x8  M3*25mm	③x4  M3.5*25mm	
④x7+1  M3.5*30mm	⑤x11+1  M3.5*35mm	⑥x10+1  M3.5*45mm	
⑦x4  M3.5*50mm	⑧x12+1  wood stick ø8*20mm	⑨x10 	⑩x2 

Cx1

Dx1

⑦x2


⑧x2




Ex1

Fx1

⑧x8



⑤x4




Ax1


Bx1

⑦x2

⑧x2




⑤x4




Gx2

②x8



Hx2

①x8




Ix2 ④x6

Jx1 ⑤x3


Kx3

Lx3




⑥x6

⑨x6



④x1

⑥x4






①x4

③x4

⑨x4

⑩x2



Note:
Please select the
hole positions
based on the
actual window
conditions.