
ASSEMBLY INSTRUCTIONS



+ Do Not Use PowerTools



+ Suggested Adults



NOTE:

- 1 Read instructions cover to cover.
- 2 Save all packaging until assembly is completed.

1 IMPORTANT SAFETY INFORMATION

Do not assemble the product if any of the following parts arrived damaged:


- Part (1) Chair back
- Part (2) Cushion
- Part (3) Upper leg frame
- Part (4) Lower leg frame
- Part (5) Foot rest

Do not assemble if any of the following Hardware parts are missing:

- Part A Bolt 1/4"*1-1/2"
- **Part B** Bolt 1/4"*1"
- Part C Bolt 1/4"*3/4"
- Part D Flat washer 1/4"
- Part E Spring washer 1/4"
- Part F Allen wrench 1/4"

2 IMPORTANT ASSEMBLY INFORMATION

Assembly Step If loosening persists, Please make sure to tighten all the bolts periodically, or use a thread locker adhesive.



+ Hardware Included

- A Bolt 1/4"*1-1/2" 5PCS
- B Bolt 1/4"*1" 8PCS



- C Bolt 1/4"*3/4" 8PCS
- D Flat washer 1/4"







- E Spring washer 1/4" 21PCS
- F Allen wrench 1/4"





ASSEMBLY INSTRUCTIONS





ASSEMBLY INSTRUCTIONS

