


Attic Cover Installation Guide






1 Open the attic entrance

Unfold and open the attic door completely to provide full access to the attic opening.



2 Position the attic insulation cover

Place the attic cover over the opening, ensuring that the **sloped zipper section** faces the direction of entry. This orientation allows for easier access when the zipper is open.



3 Secure the cover in place

Once properly aligned, **staple the insulation cover** to the wooden frame of the attic opening. Staple around the entire perimeter, spacing staples approximately **4-6 inches (10-15 cm)** apart to ensure a tight seal and prevent air leakage between the attic and living space.



4 Close the zipper completely when not in use

When the attic is not being accessed, fully close the zipper to **maintain insulation efficiency** and stop air from passing through the cover.