Assembly Instructions PARSONS DESK



Thank you for purchasing our product!


Please assemble the products with the guidance of this manual instruction. Contact our friendly customer service department with any <u>comments</u> or in case there is any missing or damaged parts or <u>hardware</u>. Replacements for missing or damaged parts or hardware are normally shipped within 2 to 3 days.

We appreciate your business!


Hardware List

ltem	Description	Part	Qty	Item	Description	Part	Qty
Α	Allen Head Bolt	6*35mm	4 pcs	F	Wooden Dowel	8*30mm	4 pcs
В	Allen Head Bolt	6*60mm	4 pcs	G	Allen Wrench		1 pc
С	Barrel Nut	8.5*10mm	4 pcs	н	Usb Hub	STREET, ?	1 pc
D	Washer	0	4 pcs	I	Plastic Cover		1 pc
E	Lock Washer		4 pcs				

Item	Description	Part	Qty	Item	Description	Part	Qty
1	Desk Top		1 pc	3	Left Side Frame		1 pc
2	Right Side Frame		1 pc	4	Connect Rail		1 pc




- 1. Place the desk top (1) on a flat, protected surface as shown.
- Attach left side frame (3) and right side frame (2) to desk top (1) using dowel (F), allen head bolt (A),lock washer (E) and washer (D). Tighten the allen head bolt (A) using allen wrench (G).



1. Insert barrel nut (C) to connect rail (4) in right direction as shown.

2. Attach connect rail (4) to left side frame (3) and right side frame (2) using allen head bot (B). Tighten allen head bolt using allen wrench (G).



2. Attach plastic cover (I) to the hole on top.

3. Peel off the sticker on usb hub (H). Stick it on where you want.