


ASSEMBLY INSTRUCTIONS



TOOLS REQUIRED



Screwdriver
(Not included)



(Included)
Allen Wrench



2 - People

ASSEMBLY RATING



EASY —————> DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.

VERSION # 25-12-05



CHECK BEFORE STARTING

☐

Are you missing anything?

Double-check all parts, hardware and accessories listed are all accounted for.

☐

Check out our Quick Tips!

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

☐

Should we send any replacements?

Are there any irregularities or flaws in the parts? We can send replacements!

☐

Prep Time!

Please review the assembly instructions and all diagrams prior to assembling.

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.



Suitable Location

Assembling near the area of the intended location is highly recommended.



Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.



Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.


ASSEMBLY AND CARE ADVICE



**FAILURE TO FOLLOW THE GUIDELINES BELOW MAY
RESULT IN INJURY AND/OR PROPERTY DAMAGE.**



Position each part correctly
and insert screws or bolts into
their respective holes.



Turn clockwise to tighten and
only tighten when step is
completed or when instructed
to do so.



Use the appropriate hand tools
or power tools for assembly.
Select steps, such as tightening
screws and/or bolts, may require
hand tools to avoid causing
damage during assembly.



Save the instructions and store
any supplied tools for later
maintenance.




After two weeks, check and
tighten any loose hardware and
repeat again every six months
thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

SIDE CHAIR




- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.




PARTS

(P1) - 2 PCS



CHAIR BACK

(P2) - 2 PCS




CHAIR SEAT

(P3) - 2 PCS



LEFT STRETCHER (L)

(P4) - 2 PCS



RIGHT STRETCHER (R)

(P5) - 2 PCS



FRONT LEG LEFT (L)

(P6) - 2 PCS



FRONT LEG RIGHT (R)

HARDWARE

(H1) - 4 PCS



M6X35mm JCBC SCREW

(H2) - 16 PCS



M6x70mm JCBC SCREW

(H3) - 20 PCS



SPRING WASHER

(H4) - 20 PCS



FLAT WASHER

(H5) - 8 PCS



M4x38mm CSK SCREW

(H6) - 1 PC




ALLEN KEY

H7 - 8 PCS




NAIL LEG




ASSEMBLY INSTRUCTIONS

Please read instructions carefully

Remove all wrapping materials, staples and packing straps from the carton. Refer to Parts List and Hardware List and ensure they are complete before you start assembling. Place all wooden parts on a clean, flat and soft surface (e.g carpet or rug) to prevent parts from being scratched.
CAUTIONS: 1) DO NOT FULLY TIGHTEN BOLTS AND NUTS UNTIL ALL PARTS HAVE BEEN ASSEMBLED.
2) DO NOT OVER-TIGHTEN BOLTS AND NUTS .
3) KEEP ALL HARDWARE PARTS OUT OF REACH OF CHILDREN.

Carton	Designation	Part List	Hardware List
	CHAIR BACK	 P1 x 2pc	 H1 x 4pc
	CHAIR SEAT	 P2 x 2pc	M6x35mm JCBC SCREW
	LEFT STRETCHER (L)	 P3 x 2pc	 H2 x 16pc
	RIGHT STRETCHER (R)	 P4 x 2pc	M6x70mm JCBC SCREW
	FRONT LEG LEFT (L)	 P5 x 2pc	 H3 x 20pc
	FRONT LEG RIGHT (R)	 P6 x 2pc	SPRING WASHER
			 H4 x 20pc Flat Washer  H5 x 8pc M4x38mm CSK SCREW  H6 x 1pc Allen Key  H7 x 8pc NAIL LEG



COMPLETE ASSEMBLY

ASSEMBLY INSTRUCTIONS


SIDE CHAIR

PARTS LIST (FOR 2 CHAIRS)

NO.	COMPONENT	QTY.
P1	CHAIR BACK	2
P2	CHAIR SEAT	2
P3	LEFT STRETCHER (L)	2
P4	RIGHT STRETCHER (R)	2
P5	FRONT LEG LEFT (L)	2
P6	FRONT LEG RIGHT (R)	2

HARDWARE LIST (FOR 2 CHAIRS)

NO.	DESCRIPTION	QTY.
H1	JCBC SCREW M6 x 35MM	4
H2	JCBC SCREW M6 x 70MM	16
H3	SPRING WASHER	20
H4	FLAT WASHER	20
H5	M4x38mm CSK SCREW	8
H6	ALLEN KEY	1
H7	NAIL LEG	8




COMPLETE ASSEMBLY

STEP 1

Assembly Chair Seat (P2) into the Chair Back (P1) by aligning Bolts(H1) fitted with Spring Washer (H3) & Flat Washer (H4) into both center pre-drilled holes . Use Allen Key (H6) to tighten the bolts.


H1 x 2		M6 x 35mm
H3 x 2		
H4 x 2		



STEP 2

Now, proceed to secure the inside corners by aligning two set of bolts, on each side of the chair seat to finish securing it to the Chair Back. See image below for corresponding hardware to use.

H2 x 4		M6 x 70mm
H3 x 4		
H4 x 4		




Insert Left Stretcher (P3) and Right Stretcher (P4) into the designated hole on Back Leg Frame (P1)


ASSEMBLY INSTRUCTIONS

MODEL : SIDE CHAIR

STEP 3

You should now install Right and Left Front Legs (P5 and P6) . Insert legs into designated holes to connect to each side stretcher previously installed. Then, secure each leg to the chair seat frame by aligning corresponding bolts on each sides see image below. Lightly tighten the bolts using Allen Key (H6) just to keep them in place .

H2 x 4	
H3 x 4	
H4 x 4	




DO NOT FULLY TIGHTEN BOLTS AT THIS POINT AS ONE LAST STEP IS STILL PENIDNG

STEP 4

H5 x 4	
M4 x 38mm	


Align Screw (H5) to fit all the stretchers. Tighten the screws by using a household screwdriver.



STEP 5


H7 x 4	
--------	---

Tap the Nali Leg (H7) to each chair Leg.



CARE AND MAINTENANCE

- SAFETY** - To avoid any risk of suffocation to children or animals, dispose off the plastic bags immediately.
- CLEANING** - Clean with damp cloth and mild detergent. Do not use bleach or abrasive products.
- FITTINGS** - Tighten bolts and nuts from time to time to ensure all parts of product are securely fitted.



ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.



Keep this handy!

Please retain this instruction manual and any order-related information for future reference.



Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting or adjusting the placement.

This product is intended for RESIDENTIAL USE ONLY and not for commercial use .

CARE AND MAINTENANCE

SAFETY - To avoid any risk of suffocation to children or animals, dispose off the plastic bags immediately.

CLEANING - Clean with damp cloth and mild detergent. Do not use bleach or abrasive products.

FITTINGS - Tighten bolts and nuts from time to time to ensure all parts of product are securely fitted.