


140.00 mm

210.00 mm

INSTRUCTION MANUAL

16" RECHARGEABLE STAND FAN



1.Green LED operating indicator

2.Oscillation control lock

3.Double DC output for LED bulb

4.USB socket

5.Red LED charging indicator

6.Stepless speed switch

7.LED switch

8.DC socket

9.Remote control

Thank you for using our product, please read the instruction manual carefully before initial use.

Please read these instructions before first use:

1.Handle

2.Back cover

3.Fixed ring of grill

4.Fan blade

5.Fixed knob of blade

6.Big fixed ring

7.Front cover

8.Protecting cover

ATTENTION

1.Please read this instruction before first use.

2.Please ensure that the voltage indicated on the appliance corresponds with the mains voltage.

3.When the led gets dim, please recharge the product.

4.Charge at least once in every 3 months for 10hours even when the appliance is not in use.

5.Please keep the fan switch in OFF status when not in use.

6.Suitable operating ambient humidity level is 0℃-40℃.

7.Avoid using in water or moist.

HOW TO OPERATE

1.Make sure the power supply is consistent with the rating of product.

2.Connect the power supply, the charge indicator turn green, then the fan can be work.

FUNCTION

Power: Turn on or turn off the fan

+ : Fan speed increase

- : Fan speed decrease

0.5H: 0.5hours timer

LED: Turn on or turn off LED light

TURN: Oscillation control lock



HOW TO CHARGE THE FAN

- Please ensure that the voltage indicated on the appliance corresponds with the mains voltage.
- Plug in the cord to AC socket.
- Red indicator shows that the battery is getting charged.
- It is a normal phenomenon of slight heat while charging the battery.

TECHNICAL DATA

- Power source: AC 110-240V 50/60Hz
- Battery: 2*3.2V 5.5Ah LiFePo4 battery
- Light source: 32 pcs Powerful SMD for light
- Blade: 16 inch
- Charge time: 12-15 hours
- Duration: 30-50 hours/LED
Fan: 5-25 hours

WARNING :

- The product should not be abandoned in life waste. The battery especially should be recycled after abandoning, as it is environmentally harmful.
- If the supply cord of the fan is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.
- This appliance is not intended for use by person(including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for the safety.
- Children should be supervised to ensure that they do not play with the appliance.

As shown in the figure, assemble the fan head and column, and tighten the two screws attached with the product.

