

Thank You For Shopping With COZAYH HOME





We value your feedback and want to hear from you. To let us know how we can improve your shopping experience, or to ask a specific question about your order, please find our contact information below.

Customer Service Line: 1.312.600.5553 (M-F 9am-5pm Central Time)

Customer Service Email: Support@cozayh.com

Website: www.cozayhhome.com

Assembly Instructions											
		SKU: PH0310-4 Laying out all the parts and hardware, identifying each part as shown may help you as you assemble the table.									
ITEM	PART	DESC.	QTY	ITEM	PART	DESC.	QTY	ITEM	PART	DESC.	QTY
A		Table top	1	D		Bottom shelf	1	G		Allen wrench	1
B		Wood base	1	E		Flat washer	4				
C		Wood base	1	F		Bolts (Ø6×50mm)	4				

STEP 1  Flip the table top upside down, attach wood base B to the table top A using bolts and flat washers.	STEP 2  Attach wood base C to the table top A using bolts and flat washers.	STEP 3  Insert bottom shelf D as shown above.	STEP 4  Finished product. Please make sure all the bolts are fully tightened before styling.
---	--	--	--



WARNING

- Do not dispose of any packaging or contents of the shipping carton until assembly is completed to avoid accidentally discarding small parts or hardware.
- Choking Hazard – Adult assembly required. It may contain small parts and sharp points.
- Do NOT use power tools.
- This product can hold a maximum load of 25 Lbs. Do NOT overload.



COZAYH HOME