












Shoe Cabinet Assembly Instructions



If you experience any issues with the item,
please reach out to our support team. We're here to help!



WARNING





1. PLEASE READ ALL INSTRUCTIONS CAREFULLY BEFORE STARTING ASSEMBLY.
2. DO NOT LET ANY SHARP OBJECTS TOUCH OR RUB THE SURFACE OF THE PRODUCT.
3. WHEN ASSEMBLING, DO NOT LET CHILDREN PLAY AROUND THE WORKING AREA.
4. PLEASE CONFIRM ALL PARTS ARE CORRECT BEFORE STARTING THE ASSEMBLY PROCESS.
5. DO NOT TIGHTEN ALL BOLTS AND SCREWS COMPLETELY UNTIL THE ENTIRE UNIT HAS BEEN ASSEMBLED AND SET UP.

ADVISE


1. DO NOT SIT OR STAND ON THIS PRODUCT. IT IS INTENDED FOR PETS ONLY.
2. THIS PRODUCT SHOULD BE ASSEMBLED BY AN ADULT.
3. PLEASE PUT THE PRODUCT ON A SMOOTH SURFACE AFTER YOU ASSEMBLED IT.
4. PLACE ALL PARTS ON A CLEAN AND SMOOTH SURFACE SUCH AS A RUG OR CARPET TO AVOID THE PARTS FROM BEING SCRATCHED.
5. THE SCREW OF HINGE ON THE DOOR ALSO CAN BE ADJUSTABLE, TO MAKE IT EVEN THEN TIGHTEN ALL SCREWS.


TOOL NEEDED




SCREWDRIVER REQUIRED
- NOT INCLUDED

PARTS






A
Top Panel
x1




B
Left Side Panel
x1




C
Divider Panel
x1




D
Right Side Panel
x1




E
Upper Left Back Panel
x1




F
Upper Right Back Panel
x1




G
Long Back Rail
x1




H
Short Back Rail
x1




I
Lower Left Back Panel
x1




J
Lower Right Back Panel
x1



K
Wide Shelf
x4



L
Narrow Shelf
x4




M
Bottom Panel
x1




N
Leg
x4



O
Leg
x1



P
Left Door
x1



Q
Right Door
x2


HARDWARE

										
1	2	3	4	5	6	7	8	9	10	
x 14 pcs	x 14 pcs	x 12 pcs	x 10 pcs	x 36 pcs	x 6 pcs	x 6 pcs	x 16 pcs	x 16 pcs	x 32 pcs	
										
11	12	13	14	15	16	17	18	19	20	21
x 6 pcs	x 4 pcs	x 22 pcs	x 2 pcs	x 2 pcs	x 2 pcs	x 5 pcs	x 3 pcs	x 6 pcs	x 6 pcs	x 24 pcs

ASSEMBLY INSTRUCTIONS


1

- Install Cam Bolts (1) into Left Side Panel (B), Divider Panel (C), and Right Side Panel (D) using a Phillips screwdriver.



2



- Attach Back Rails (H, G) to Divider Panel (C) using Cam Lock (2). Then, connect Side Panels (B, D) to Back Rails and secure them with Cam Locks (2).
- Slide the Back Panels (I, J) into the grooves of the Side Panels (B, D) and the Divider Panel (C).



3


- Insert Wood Dowels (3) into Side Panels (B, D) and the Divider Panel (C).
- Secure the Bottom Panel (M) to the assembled frame using Screws (6). Attach the Gasket (17) to the Legs (N, O) using Screws (4).

			
3 x 6 pcs	4 x 10 pcs	6 x 6 pcs	17 x 5 pcs





4


- Secure the Legs (N, O) to the Bottom Panel (M) using Screws (13). Then stick on the EVA Gasket (12).
- Turn the cabinet upright. Slide the Back Panels(E, F) into the grooves of the Side Panels (B, D) and the Divider Panel (C).



5

- Install Cam Bolts (1) into the Top Panel (A) and secure Parts (14) to the Top Panel (A) using Screws(13).
- Attach the Top Panel (A) to the cabinet using Wood Dowels (3) and secure it with Cam Locks (2).




						
1 x 6 pcs	2 x 6 pcs	3 x 6 pcs	13 x 2 pcs	14 x 2 pcs	NO!	YES !



6

- Reinforce the cabinet by installing Back Panel Wedges (8) with Screws (9).
- Secure the Angle Block(20) to the inside of the cabinet using Screws (21).




			
8 x 16 pcs	9 x 16 pcs	21 x 24 pcs	20 x 6 pcs



FURNITURE TIPPING RESTRAINT











WARNING: Tip-Over Hazard.



7

- Serious or fatal crushing injuries can occur from furniture tip-over. ALWAYS secure this cabinet to the wall using the provided Anti-Tip hardware.





NOTE : Wall fixing are not supplied with this product as different wall materials require different types of fixing devices (such as Rawl plugs on brick work). You must use fixing devices suitable for the type of

wall you intend to mount this product to. Please ensure that the head of any screw used has a diameter greater than the diameter of the mounting hole on the product and that the fixing is safe and secure before use.

The screws and washers which fix the brackets to furniture panels are included in your pack.


OPTION 1

Shelves in Horizontal Position.




OPTION 2






Shelves in Horizontal Position.



OPTION 1







10
x 32 pcs



OPTION 2




10
x 32 pcs






8

- Attach the Hinges (7) to the Doors (P, Q). Mount the Doors to the cabinet using Screws (5).

	
5	7
x 36 pcs	x 6 pcs



Note: Adjust hinges if door gaps are uneven (scan QR code for video).



9

- Install the Handles (18) onto the Doors (P, Q) using Screws (19).
- Attach the mute stickers (11).

		
18 x 3 pcs	19 x 6 pcs	11 x 6 pcs

