



Assembly Manual

Dining Chair




Please read this manual carefully before any operation and keep it properly for future use.


Assembly-note:




- ① Put a protective mat on the ground and handle the product with care.




- ② Two people are preferred.



- ③ Contact us if you have any confusions








Exploded
diagram:




NO.	Name	PCS
1	Front leg	2
2	Back leg	2
3	Seat	1
4	Backrest	1

Accessory list:

A 		B 		C 	
Bolt	5	Bolt	8	Bolt	13
D 		E 			
Bolt	13	Allen wrench	1		

Step1:


1



Step2: **Attention:**

Tightened the screws in 100% after all connection in right position.


2





Step3:

Tightened the screws in 50% after all connection in right position.

3




Tighten the screws to 50% tightness





Step4:

Tighted the screws in 50% after all connection in right position.

4




Tighten the screws to
50% tightness



Attention:

Tightened the screws in 100% after all connection in right position. Legs levels can be modified by adjustable foot nails under bottom of the front legs.

Done



Warning

- Please keep the product away from children while assembling.
- Do not let children play or jump on the product.
- Do not stand on the item or use as a step ladder.
- Prior to use, please check to see if there's any loosening screw or part.
- Make sure that each screw and part is correctly installed and securely fastened.

Care and Maintenance

- Use a soft clean cloth that will not scratch the surface when dusting
- There's no need to use furniture polish.If you need, test it first in an inconspicuous area.
- Using solvents of any kind on your furniture may damage the finish.
- Never use water to clean your furniture as it may cause damage to the finish.
- Liquid spills should be removed immediately.
- Gently blot the spill with a soft clean cloth to avoid rubbing.

Further advice about the furniture care

- It is best to keep your furniture in a climate-controlled environment.
- Extreme temperatures and humidity changes can cause fading.warping, shrinking and spitting of wood.
- We recommend to keep furniture from sunlight exposure to avoid possible surface damage.
- Proper maintenance and cleaning at home will extend the life of your purchase.
- Following these important and helpful tips will help retain your furniture's performance even when it ages.
Periodically(every 90 days) make sure the screws are fully tightened.