ASSEMBLY INSTRUCTION DINING BENCH

DO NOT FULLY TIGHTEN BOLTS UNTIL THE ENTIRE ITEM IS COMPLETELY ASSEMBLED

A=1PC	B=2PCS	C=1PCS	D=2PCS

No.	Description.		Q.Ty
1	BOLT Ø 1/4" x 30mm	(0)	10 Pcs
2	FLAT WASHER		10 Pcs
3	SPRING WASHER	0	10 Pcs
4	BOLT Ø 1/4" x 45mm	(a)	4 Pcs
5	ALLEY KEY		1 Pcs

STEP 1







