



ASSEMBLY INSTRUCTIONS



TOOLS REQUIRED



Screwdriver
(Not included)



Allen Wrench



2 - People

ASSEMBLY RATING



EASY

► D.FFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



CHECK BEFORE STARTING

☐

Are you missing anything?

Double-check all parts, hardware and accessories listed are all accounted for.

☐

Check out our Quick Tips!

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

☐

Should we send any replacements?

Are there any irregularities or flaws in the parts? We can send replacements!


☐

Prep Time!

Please review the assembly instructions and all diagrams prior to assembling.


PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.



Suitable Location

Assembling near the area of the intended location is highly recommended.




Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches and damages.



Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.


ASSEMBLY AND CARE ADVICE



**FAILURE TO FOLLOW THE GUIDELINES BELOW MAY
RESULT IN INJURY AND/OR PROPERTY DAMAGE.**



Position each part correctly
and insert screws or bolts into
their respective holes.



Turn clockwise to tighten and
only tighten when step is
completed or when instructed
to do so.



Use the appropriate hand tools
or power tools for assembly.
Select steps, such as tightening
screws and/or bolts, may require
hand tools to avoid causing
damage during assembly.




Save the instructions and store
any supplied tools for later
maintenance.


After two weeks, check and
tighten any loose hardware and
repeat again every six months
thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

Q BED




- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.




PART

① 1 pc




HEADBOARD

② 1 pc




HB - LEG RIGHT

③ 1 pc




HB - LEG LEFT

④ 1 pc




FOOTBOARD

⑤ 2 pcs




SIDE RAIL

⑥ 4 pcs




SLAT
1540 x 42 x 17mm

⑦ 4 pcs



VERTICAL LEG
219 x 29 x 29

⑧ 1 pc



HEADBOARD STRETCHER

HARDWARE

HARDWARE INSIDE HEADBOARD / FOOTBOARD / SLAT / VERTICAL LEG / HB STRETCHER.

Ⓐ 6 pcs



Bolt M8x40mm

Ⓑ 6 pcs



Lock Washer
M8

Ⓒ 14 pcs



Flat Washer
M8

Ⓓ 1 pc



Allen Key M5

Ⓔ 1 pc



Adapter

Ⓕ 8 pcs




Bolt M8x20mm

Ⓖ 8 pcs



Panhead screw
M4x30mm

Ⓗ 4 pcs



Bolt M6x35mm

Ⓘ 4 pcs




Lock Washer
M6

Ⓙ 4 pcs




Flat Washer
M6

Ⓚ 1 pc



Allen Key M4

is packed in 2 cartons.


CARTON	DESCRIPTION	PART	HARDWARE
	QUEEN HEADBOARD	①  x 1	 A x 6 PCS  B x 6 PCS  C x 14 PCS  D x 1 PC  E x 1 PC
	QUEEN HB - LEG RIGHT	②  x 1	
	QUEEN HB - LEG LEFT	③  x 1	
	QUEEN FOOTBOARD	④  x 1	 F x 8 PCS  G x 8 PCS  H x 4 PCS  I x 4 PCS  J x 4 PCS  K x 1 PC
	QUEEN SLAT	⑥  x 4	
	QUEEN VERTICAL LEG	⑦  x 4	
	QUEEN HB STRETCHER	⑧  x 1	
	QUEEN/KING SIDE RAIL	⑤  x 2	

ASSEMBLY INSTRUCTIONS

1


- Part ① 1 pc
- Part ② 1 pc
- Part ③ 1 pc
- Hardware ① 6 pcs
- Hardware ② 6 pcs
- Hardware ③ 6 pcs
- Hardware ④ 1 pc

Use Allen Key (#D) to attach the HB Leg Right (#2) and HB Leg Left (#3) to the Headboard (#1) by using Bolt (#A) with lock washer (#B) and flat washer (#C)



2

- Part ②
- Part ③
- Part ⑧
- Hardware ④ 4 pcs
- Hardware ⑤ 4 pcs
- Hardware ⑥ 4 pcs
- Hardware ⑦ 1 pc




Attached HB Stretcher (#8) and (Use Allen Key (#K) to attach the HB Leg Right (#2) and HB Leg Left (#3) by using Bolt (#H) with lockwasher (#I) and flat washer (#J)

ASSEMBLY INSTRUCTIONS

3

- Part ④ 1 pc
- Part ⑤ 2 pcs
- Hardware ⑥ 8 pcs
- Hardware ⑦ 8 pcs
- Hardware ⑧ 1 pc


Use Allen Key (#D) to attach the Side rail (#5) to Headboard (#1) and Footboard (#4) by using Bolt (#F) with flat washer (#C).





4

- Part ⑥ 4 pcs
- Part ⑦ 4 pcs
- Hardware ⑧ 4 pcs
- Hardware ⑨ 4 pcs

Attach Adapter (#E) to Headboard (#1)



Attached Vertical Leg (#7) spread slat evenly in to Side Rail (#5) and secure by using Panhead Screw (#H). Tighten with Screw Driver.



ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and for screw are properly tightened and secured.

✓ Keep this handy!

Please retain the instruction manual and any order-related information for future reference.

✓ Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting or adjusting the placement.

This product is intended for RESIDENTIAL USE ONLY and not to commercial use.