

Floor Lamp

[Instruction Manual]




Please pay attention to the warning signs
Read the instructions with caution before operating
and keep it properly

CAUTION


1. Before assembly, place all parts on a clean flat surface and check each part for defects that may occur during shipping.
2. Inspect wire insulation for any cuts, abrasions or exposed copper that may have resulted from shipping. If there are any defects in the wire, DO NOT continue assembling. Please send an email to our Customer Service immediately.
3. Consult a qualified electrician if you have any electrical questions.
4. Never drape clothes over the lamp.
5. To reduce the possibility of tipping over, we recommend placing the lamp behind furniture and keeping children and pets away.
6. To prevent children from suffocating and choking, keep them away from packing materials.
7. Please keep this manual and hand it over when you transfer the product.

PACKING LIST:



ASSEMBLY INSTRUCTIONS

Before assembly, check the packing listing to make sure all parts are present;



1.Screw the 1-2-3-4-5-6-7-8-9-10 parts together clockwise in turn as shown, and gently pull out the excess power cord from the bottom of the lamp base (6).

2.Place the shade (8) on the socket and screw the socket ring (9) to fix the shade.

Specifications:

- Materials: Metal, Paper
- Input Voltage: 220-240Vac 50Hz
- Max.Load Power: LED Bulb 12W or Incandescent Bulb 60W
- Socket Type: Standard Medium E27

One Year Limited Warranty

Supported by our professional R&D team and QC team, we provide One Year Warranty for materials and workmanship from the purchase date. Please note that the warranty does not cover damage caused by personal misuse or improper installation.

Please attach your Order ID and Name so that our dedicated customer service team can help you better.



Disposing of the package

The package consists of cardboard and respectively labelled plastics that can be recycled.
Provide these materials for recycling.



Disposal of the product

This electrical appliance cannot be disposed of with domestic waste. Consumers are obligated to hand over electrical appliances to the manufacturer, the point of sale or a public collection point set up free of charge, based on resource conservation and environmental protection. Before the device is discharged, installed batteries or accumulators must be removed and disposed of separately.



Disposal of batteries and accumulators

Cd Hg Pb

Old batteries must not be disposed of with domestic waste, as they may contain harmful substances or heavy metals which may harm the environment. Waste batteries and accumulators must be disposed of in accordance with the prescribed regulations. Consumers are obliged to hand over batteries and accumulators free of charge to a public collection point set up for this purpose. Do not heat the batteries – Explosion hazard!



EU-Conformity

This product complies with conformity requirements of the applicable legislation.