




INSTRUCTION  
 ANWEISUNG  
 取扱説明書  
 INSTRUCTION  
 사용설명서



**FR**  
 Ce meuble se recycle,  
 s'il n'est plus utilisable  
 déposez-le en déchèterie.  
 Notice à trier.

1 x1



2 x1



3 x1



4 x1



5 x2



6 x1



7 x11



A \*14



B \*14




C \*22



D \*8



E \*2




F \*4





G \*4




1




- A x2
- B x2
- D x4




2




- A x2
- B x2
- D x4



3




- C x44




5

- A x6
- B x6



6

- A x4
- B x4



7

- F x4
- G x4

