Armless Chair
Assembly Manual

FSC
www.fsc.org
100%
Wood from well-managed forests
FSC® C183324



⚠ CAUTION THIS ASSEMBLY MANUAL CONTAINS IMPORTANT SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Parts

A  Headrest	B  Seat	C Plastic Feet×4

Before you begin: Locate both the Hardware Kit and the Plastic Feet (C) at the bottom of the Armless Chair Seat.



Step 1: Tip over the Armless Chair, remove the 4 Plastic Feet (C), align them with the holes as shown, and tighten the Plastic Feet by hand.



Step 2: Align the Screw Rod with the hole at the bottom of the Headrest (A), screw it in and leave 5 cm exposed; then insert the exposed Screw Rod into the hole on the Backrest, place a Washer on the Five-Pointed Star Nut, and then screw it in to secure the Headrest.



How to Connect

Step 1: Lift the side of the sofa with the protruding side brackets, insert it into the side slots on the opposite side, to lock them into place.



Step 2: Connect one end of the Power cord into the DC adaptor located at the bottom of the arm.Plug the other end of power cord into the power outlet.
Note: After all the connections are made, the green LED will be lit up.