














ASSEMBLY INSTRUCTIONS





















Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts, which may have came loose inside the carton during shipment. Count all parts and material hardware, then compare with parts list to be sure all parts are present. If any parts are missing or damaged, phone, fax, or mail to our Customer Service Department for efficient and speedy service. Please indicate the model number and code letter of part(s) needed.

NOTE: In order to prevent damage during assembly, please assemble this item with at least two people.

IMPORTANT NOTE: Follow instructions listed below in proper sequence as numbered to assure fast, easy and correct assembly.

PARTS LIST		
<p>A</p>  <p>TOP PANEL-1PC</p>	<p>B</p>  <p>BOTTOM PANEL -1PC</p>	<p>C</p>  <p>LEGS -4PC</p>
<p>D</p>  <p>SIDE LEFT PANEL-1PC</p>	<p>E</p>  <p>SMALL PANELS-2PCS</p>	<p>F</p>  <p>LEFT DOOR -1PC</p>
<p>G</p>  <p>RIGHT DOOR -1PC</p>	<p>H</p>  <p>LEFT BACK PANEL -1PC</p>	<p>I</p>  <p>RIGHT BACK PANEL -1PC</p>
<p>J</p>  <p>SHELVES -4PCS</p>	<p>K</p>  <p>FRONT PANEL -1PC</p>	<p>L</p>  <p>ACROSS PANEL -1PC</p>


NOTE: THE SURFACE WITH THE STICKER IS THE BACK SIDE.

<p>M</p>  <p>SIDE RIGHT PANEL -1PC</p>	<p>1</p>  <p>CAM - BOLTS -15PCS</p>	<p>2</p>  <p>CAM - BOLTS -15PCS</p>
<p>3</p>  <p>SCREWS -2PCS</p>	<p>4</p>  <p>HANDLES -2PCS</p>	<p>5</p> <p>Ø13*1-3/4"</p>  <p>BOLT -8PCS</p>
<p>6</p>  <p>ALLEN WRENCH -1PC</p>	<p>7</p>  <p>SHELF SUPPORTS -16PCS</p>	<p>8</p>  <p>SCREWS -8PCS</p>
<p>9</p>  <p>LARGE MAGNET -1PCS</p>	<p>10</p> <p>Ø7*5/8"</p>  <p>SCREWS -38PCS</p>	<p>11</p>  <p>FEMALE MAGNET -4PCS</p>
<p>12</p> <p>Ø5*1/2"</p>  <p>SCREWS -4PCS</p>	<p>13</p> <p>Ø6*1/2"</p>  <p>SCREWS -36PCS</p>	<p>14</p>  <p>HINGES -6PCS</p>
<p>15</p>  <p>HOOKS -4PCS</p>	<p>16</p>  <p>ANCHOR-4PCS</p>	<p>17</p>  <p>PLASTIC TIE-2PCS</p>

NOTE: THE SURFACE WITH THE STICKER IS THE BACK SIDE.


18

Ø8*1-1/2"




Screw-4PCS

19



FLAT WASHER-8PCS

20



MAGNET -1PC



21



CAM-TOOL-1PCS




NOTE: THE SURFACE WITH THE STICKER IS THE BACK SIDE.

NOTE: • UPON OPENING, THOROUGHLY CLEAN ALL WOOD SURFACES TO REMOVE DUST AND DIRT THAT MAY HAVE SETTLED ONTO FINISH DURING SHIPMENT. IN ORDER TO PREVENT DAMAGE DURING ASSEMBLY, PLEASE ASSEMBLE THIS ITEM WITH AT LEAST TWO PEOPLE.




NOTE: TURN THE CAM-BOLT SCREWS UNTIL THEY ARE TIGHT, THE SHOULDER SHOULD BE AGAINST THE SURFACE OF THE PART.


HOW TO USE THE CAM-TOOL




NOTE: • THE ARROWS ON THE HIDDEN CAM-LOCKS SHOULD POINT TO THE CAM-BOLTS




1) ASSEMBLE THE LEGS.




2) ASSEMBLE THE FRONT PANEL.




3). ASSEMBLE THE TOP PANEL.




4). ASSEMBLE THE ACROSS PANEL.




5). ASSEMBLE THE BOTTOM PANEL. _____




6). ASSEMBLE THE TOP PANEL.




7). ASSEMBLE THE SMALL PANEL AND MAGNET.




8). ASSEMBLE THE DOORS.




9). ASSEMBLE THE DOORS AND SHELF SUPPORTS.



9). ASSEMBLE THE SHELVES.



10). ASSEMBLE THE BACK PANEL.



11). ASSEMBLE ANTI-TIP HARDWARE.



**Shelf Weight Capacity:
35lbs**