

Austin Upholstered Chair Instruction Manual

• Product Parts



• Installation

- Step 1: Insert and push each caster into the base.
- Step 2: Insert the gas lift cylinder into the center of the base.
- Step 3: Tighten the tilt mechanism with screws.
- Step 4: Insert top of the gas lift cylinder into the mounting hole.

• Function

1. Adjustable seat height.
2. 360° freely swivel.
3. Adaptive swing function.

• Instruction

1. Use the lever on the right side to adjust the seat height.
2. Use the lever on the left side to adjust and lock tilt angle (Rotate the lever downward to open adaptive swing function and rotate the lever upward to close adaptive swing function and lock the tilt angle).
3. Use the knob to adjust the tilt tension (Turn the knob clockwise to tighten and turn the knob counterclockwise to loosen).



• Cautions

- (1) Due to large tilt angle, please don't use excessive force when leaning back.
- (2) Leather Maintenance
 1. Keep dry and store it in a cool and ventilated place.
 2. Do not expose to sunlight, fire, water, sharp objects and chemical solvents.
 3. If there are stains, please use special leather cleaner to clean and care it.