


材质: 128g铜版纸 尺寸: 100x140mm 印刷: 单黑双面印刷 装订方式: 折页


货前打样

Instruction Manual

LED Floor Lamp



Installation



PAGE:01

English

Introduction

Dear customer,

Thank you for choosing Floor lamp. This introduction will help you to properly install and use your new lamp. Please read these carefully before using and keep them for future reference.

If you require further assistance, please contact our online customer service by e-mail.We wish you a lot of fun with your new lamp!

Package contents

- 1 x Floor Lamp
- 1 x Remote Controller
- 1 x Instruction Manual

1 x Power Adapter

2 x AAA battery

Safety Instructions

1. DO NOT place the floor lamp in a high temperature or humid space.

2. DO NOT put it in the place facing the light source.

3. DO NOT privately disassemble, repair, or replace any floor lamp parts. Including luminaire parts, power, and cord.

4. DO NOT cover floor lamps with flammable materials.

5. DO NOT spray any liquid on the floor lamp.

6. The cord should be replaced by the manufacturer, service agent, or qualified person when the external cord of the luminaire is damaged.

7. The light source of this luminaire is irreplaceable; when the lifetime of the light source comes to the end, the entire luminaire should be replaced.

Warranty

If the product has any manufacturing defect, please contact customer service via e-mail with your order number and other details to the problem. We will send you further information about the return or exchange.

PAGE:02

Specification

Model	MF30021.1
Input	AC100-240V 50/60 Hz
Output	DC 24V1.5A
Power	27W+6W
Color Temperature	3000K—6500K
Materials	Iron +PMMA
Lifespan	30,000h

Usage

① Touch Control

● Main lamp switch

Short press to turn on/off the lamp, Long press to set the timer for 1 hour.

● Main lamp dimmer switch


Short press to adjust the color temperature, long press to adjust the brightness.

● Sub lamp switch

Short press to turn on/off the main lamp, Long press to set the timer for 1 hour.

● Sub lamp dimmer switch

Short press to adjust the color temperature, long press to adjust the brightness.



PAGE:03

② Remote Control

Main lamp


Short press On/Off

Long press timing

Sub lamp

Short press On/Off

Long press timing



How to rematch the lamp and remote control

If the remote control cannot be controlled, please rematch according to the following steps:

1. Remove the power plug.

2. Press and hold on to the remote control's switch button until match successfully.

3. At the same time, plug in the floor lamp power plug and wait for two seconds, when led lights flash, matching successfully.

PAGE:04

Model:MF30021.1

Model NO: MF300211

Manufacturer: Guangdong Ansionadarry Technology Co..

Add: Room 301, Building 1, No.7, Yangian 2nd Road, HoujieTown,

Dongguan City, Guangdong Province, China

EC

REP

FC

CE

Recycle

RoHS

Intertek

Model:MF30021.1

Made in China