



ASSEMBLY INSTRUCTION FOR
LT-K291 / LT-K292 / LT-K293 / LT-K294




CAUTION:When tightening the screws,tighten sequentially.
Do not tighten any screws fully and then towards the next one.
When every part is OK,then tighten all the screws.



① X 2	② X 2	③ X 2	④ X 2
⑤ X 4	⑥ X 8	⑦ X 2	

Ax 16+1	Bx 16+1	Cx 8+1	D X 8
M6x10	M6x25	Ø5x38	Ø20xM6x12
E X 1 S4x57	F X 1 S3x57		


STEP1



(E) L

(A) X 8

STEP3




(F) V

(E) L

(C) X 2

(B) X 4

STEP2



(F) V


(E) L

(C) X 2

(B) X 4

If the hole is a little bit out of place, please adjust the frame to find the matching hole, then put the screw into the hole. Before tightening, please make sure all of the screws are already put into the slots, then you can start to tighten all of the screws to finish the assembly.

STEP4



(D) X 4

Thank you for choosing this product!