

IMPORTANT, RETAIN FOR FUTURE REFERENCE READ CAREFULLY

Before you start



Warnings

IMPORTANT, RETAIN FOR FUTURE REFERENCE READ CAREFULLY

See enclosed instructions for assembly, safety and care information.

Failure to follow the warnings could result in serious injury.

Handle heavy parts with care.

Ensure that this product is fully assembled as illustrated before

Keep small parts out of reach of children.

Do not stand or climb onto this product.

This product is intended for **Domestic Use** only.

Ensure the product is always placed on the firm and level ground.

Furniture can be dangerous if incorrectly used. No liability will be accepted for damage or injury caused by incorrect use of this product.



Dos

When you are ready to start, make sure that you have the right tools, plenty of space and a clean, dry area for assembly.

Unwrap all packaging materials and place the components on suitable surface to prevent scratching your product.

Check the pack and make sure you have all parts listed.

Check all screws and bolts are tightened and inspect regularly.

We recommend the use of furniture covers to protect your product when not in use.

During bad weather or in winter months, the product should be stored in a cool, dry place. Before storage, ensure that the product is clean and dry.

To clean, wipe down with a sponge and warm soapy water and wipe with a clean, dry cloth.

When cleaning glass panels use a damp cloth or leather with washing up liquid or soft soap if necessary; do not use washing powders or any other substances containing abrasives since these substances scratch glass.



✓ Don'ts

Never tilt the chair during use.

Do not stand or climb onto the product.

Do not use power tools to construct this product.

Do not sit or lean onto the arms of this product.

Do not use this product if parts are missing, damaged or worn.

Never use scourers, abrasives or chemical cleaner.

Do not use this product as a ladder as this could lead to the product becoming unbalanced and overturning.

Do not place very hot or very cold items on this product surface.

Never drag furniture when moving it, always lift it.

Do not use the glass top as a chopping surface. Do not strike glass with hard or pointed items.

Number of people required for assembly

One person



Time to assemble

No need of assemby

Tools required

No tools required

Instructions for use of Chairs

Always be careful when you use this kind of articulated product.

Don't pinch the fingers when folding and unfolding.

Children are not allowed to use this chair without adult's presence and quidance!

Unfolding

Lift the chair, unfold the seating panel and backrest as below diagram.

Warning: Please make sure four legs of chair should be fully extended and firmly placed on the flat ground.




Adjust the two armrests simultaneously to have a suitable backrest angle for your comfortability.

Folding

Please fold the chair as below diagram.



Never tilt this product during use. Ensure this product is always placed firmly on the ground.



PLEASE KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE